HP150 Propane Construction Heater UT-65046 - Exploded View



Ref #	Part #	Description	Qty	Context Note
1		SCREW- #10-16 x 1/2	6	Standard Hardware Item. Available Locally.
2	0052944	HANDLE	1	
3	0108601	SHELL- Upper	1	
4	0052945	SHIELD- Heat	1	
5		SCREW- Handle #10-16 x 3/4"	2	Standard Hardware Item. Available Locally.
6	0108603	COMBUSTION CHAMBER	1	
7	0052932	NUT- 14mm	1	
8	0108604	SENSOR- Flame	1	
9		SCREW- #6-32 x 3/8"	1	Standard Hardware Item. Available Locally.
10		SCREW- #10-16 x 3/8"	2	Standard Hardware Item. Available Locally.
11	A0108605	ASSY. NOZZLE	1	
12	0108632	SCREW- #8-18 x 3/8"	1	
13		SCREW- #10-16 x 1/2	16	Standard Hardware Item. Available Locally.
14	0108608	FAN	1	
15	0108609	MOTOR	1	
16	0053124	GUARD- Fan	1	
17	0052933	PLUG- Spark	1	
18	0108610	CABLE- Ignition	1	
19		SCREW-#8-18 x 1/4"	2	Standard Hardware Item. Available Locally.
20	0114518	SCREW-#8-32 x 1/4"	2	
21	0108612	BRACKET- Motor	1	
22	0052938	BUMPER- Rubber	2	
23	0108637	SHELL- Lower	1	
24	0052923	BUSHING- Snap	3	
25	0108641	BUSHING- Shorty	2	
26	0052949	NUT- Hex Jam	2	
27	0108613	RELAY	1	
28	0052914	NUT- Clip	6	
29	0108614	TUBE- Fuel	1	
30	0108615	SCREW- #6-20 x 7/8"	2	
31	0108645	SCREW- #8-15 x 1/2"	2	
32	0108616	CONTROL D.S.I.	1	
33	0108617	SOLENOID VALVE	1	
34	0053123	COVER- Side	2	
35	0052949	NUT- 1/4-20	6	
36	0108618	LOWER SHELL CRADLE	1	

Ref #	Part #	Description	Qty	Context Note
37	0108644	BASE	1	
38	0108642	SWITCH- On/Off	1	
39	0108643	BOLT- 1/4-20 x 3/8"	6	
40	0052913	BUSHING- Strain Relief	1	
41	0108622	CORD- Power	1	
42	0108626	CAP- Sleeve	1	
43	0108627	BOARD- Terminal	1	
44	0108628	AIR SWITCH	1	
45	0108629	SCREW- #4-40 x 3/4"	2	
46	0108630	NUT- #4-40	2	
47	0108631	BRACKET- Air Switch	1	
48	0108633	VALVE- Shut-Off LP Gas	1	
	0108634	REGULATOR AND HOSE ASSY. (Not Shown)	1	
	0108635	REGULATOR VALVE (Not Shown)	1	
	0108636	HOSE ASSY. (Not Shown)	1	
	0052903	THERMOSTAT- Hang-up (Not Shown) (Optional)	1	

HP150 Propane Construction Heater UT-65046 - Wiring Diagram