



Parts List for HP180K-B3 Type 1

Item Number	Part Number	Description	Qty Required
2	5103069-12	CHARGER	1
4	311993-00	SCREW	3
5	486562-00	SCREW	1
6	498099-00	SCREW	2
7	5101940-06	TRANSMISSION	1
8	5100111-00	ACTUATOR FWR/REV	1
9	5104509-48	VSR SWITCH	1
10	5100153-01	SHIFTER WIRE	1
11	5100101-05	SHIFTER	1
12	5101812-00	COVER, TOP	1
14	5101937-01	CLAMSHELL SET	1
16	5103096-00	CHUCK SCREW	1
17	5103032-03	KEYLESS CHUCK	1
18	5102349-11	MOTOR & PINION	1
19	5102206-04	NAMEPLATE	1
20	000000-00	No Longer Available	1
21	5100035-03	SPRING	2
866	90553604	BATTERY PACK	1