



## Parts List for HP18VSB-2 Type 1

Item Number	Part Number	Description	Qty Required
1	5145507-03	SCREW	1
4	5145395-01	SIDE COVER	1
5	5145486-07	CLAMSHELL SET	1
6	5100035-03	SPRING	2
7	5146420-02	SCREW	1
12	90506742	KEYLESS CHUCK	1
13	5145510-00	SWITCH, VSR	1
14	5103036-00	RING,MOTOR	1
15	90529873	MOTOR & GEARBOX	1
16	90543712	NAMEPLATE	1
17	5145396-04	SUPPORT	1
18	5145492-01	TOP COVER	1
19	5146445-00	SHIFTER BUTTON	1
20	5145488-00	ACTUATOR FWR/REV	1
21	148354-03	BIT CLIP	2
22	5145398-03	SUPPORT PLATE	1
23	5146443-01	COVER PLATE	1
24	5145507-02	SCREW	2
25	5146420-01	SCREW	4
26	607918-41	SCREWDRIVER BIT	2
27	5100034-00	TERMINAL BLOCK	1
28	5146420-00	SCREW	1
862	90528790	STORAGE BAG	1
866	HPB18	BATTERY	2
867	5102026-00	BATTERY CAP	1
871	90532613	CHARGER	1