




HPW1000E Pressure Washer UT-01802 - Exploded View



Ref #	Part #	Description	Qty	Context Note
1	01785		0	Not used on this product
2	00037	Not used on this product	1	
3	01426		1	
4	49907		1	
5	49960		1	
6	80083	CAPSCREW- Hex Hd., 5/16-18 x 3/4" Grd. 5	4	
7	86303	PIN - Cotter (3/32 x 1 1/8")	2	
8	JA452012		2	
9	499211		1	
10	JA993958	WHEEL & TIRE Push W/B Wheels	2	
11	49923		1	
12	81162	NUT- (5/16-18) (111DP2-1)	8	
13	83030	WASHER- Lock (5/16") (111DP2-1)	8	
14	499581		2	
15	49959		2	
16	499221		1	
17	80288	SCREW- Cap hex hd. (5/16-18 x 1 3/4")	4	
18	49967		1	
19	49974		1	
20	01405		1	
21	49911		1	
22	0151914		4	
23			1	For engine replacement parts locate the engine brand name, model number, and type number and consult the appropriate dealer in your area.
24	0151928		1	
25	0151932		4	
26	0151930		1	
27	49975		1	
28	A02244	SPRING & ADAPTOR	1	
	02243	Screen & Gasket	1	
31	49968		1	
32	49910		1	

Ref #	Part #	Description	Qty	Context Note
33	49914	49914	1	
34	01584		1	
35	01794		1	
36	A0152022		1	
37	A0152028		1	

HPW1000E Pressure Washer UT-01802 - Hose & Wand Assy.




Rendered by LeadVenture, Inc.

Ref # Part # Description Qty Context Note

1	49913	49913	1
2	49916	49916	1
3	49917	49917	1
4	49918	49918	1
5	01695	01695	1
6	01577	01577	1
7	49915	49915	1
8	49912	49912	1
9	49914	49914	1

HPW1000E Pressure Washer UT-01802 - Pump



Rendered by LeadVenture, Inc.

Ref #	Part #	Description	Qty	Context	Note
1	0151901		4		
2	0151902		4		
3	A0151903		1		
4	0151905		1		
5	A0151906		2		
6	A0151907		1		
7	0151937		2		
8	0151911		2		
9	0151912		2		
10	0151917		2		
11	0151914		12		
12	0151915		1		
13	0151918		1		
14	0151916		1		
15	0152020		1		
16	0152019		1		
17	0151934		1		
18	0151923		1		
19	0151935		1		
20	0151921		1		
21	0151920		2		
22	0151919		2		
23	0151913		1		
24	0151924		1		
25	0151930		1		
26	0151936		1		
27	0151926		1		
28	0151925		2		
29	0151909		2		
30	0151908		2		
32	0151904		4		
34	49975		1		