



Parts List for HT022 Type 2

Item Number	Part Number	Description	Qty Required
1	157315-00	WASHER,SPRING	1
2	148902-00	WASHER,PLAIN	1
3	854978-00	WASHER,SHIM	1
6	90541380	SWITCH	1
9	90514920-00	BLADE & GEAR	1
10	151625-00	BLADE,POLARIZED	1
11	98022-20	SCREW	2
12	376614-01	SPACER	7
14	158495-00	SCREW,TAPTITE	4
15	747329	SCREW	2
16	90524194	GUARD	1
17	90514910	AUXILIARY HANDLE	1
23	330019-03	SCREW	8
29	90529921-01	CONTROL KNOB	1
30	90526635	KNOB	1
31	90512304	BOLT	1
36	87486-00	CONTACT,TERM.	1
37	137646-00	TERMINAL	2
38	387542-00	BRUSH	2
39	038738-00	NUT	1