


HVT 52



1.1998

Spare parts

Ersatzteile

Pièces détachées

Reserve onderdelen

Repuestos

Reservdelar

- 514 91 72-00
- 513 75 35-00
- 513 79 06-00

