



BOSCH

Cordless Grass Shear

ISIO | 3 600 H33 082

Table of Content


Spare parts list.....	2
Illustration - Type.....	3

Spare parts list

Item	Part Number	Description	
23	1 619 X06 081	Set of knives	LONG
23/25	2 609 001 986	Knife Guard	LONG
653	1 619 X06 486	Charger	
654	1 619 X06 082	Set of knives	SHORT
654/25	2 609 004 099	Knife Guard	SHORT
655	2 609 003 414	Extension Set	
804	1 619 X05 508	Cover	BLACK
899	1 619 X05 510	Cordless Grass Shear	3,6V

Illustration - Type - E

3 600 H33 A00
Stand | 12-07-04
Issue | 12-09-05 **Fig. /Abb. 1**



Änderungen vorbehalten
Modifications reserved
Modifications reserves
Salvo modificaciones