


PORTER-CABLE DRILLS

619 620 621



Parts List for J-620 Type 4

Item Number	Part Number	Description	Qty Required
1	869802	ARMATURE 115V	1
1	811350	BAFFLE	1
1	811531	FAN	1
2	000000-00	No Longer Available	1
3	N119739	BRUSH & SPRING	1
3	694301	BRUSH HOLDER	1
3	694298	BRUSH INSULATOR	1
4	000000-00	No Longer Available	1
5	693720	CORDSET	1
11	330003-85	BEARING	1
15	848131	BEARING	1
19	839837	NEEDLE BEARING	1
19	330003-17	BEARING,BALL	1
20	811546	ACTUATOR	1
22	000000-00	No Longer Available	1
35	000000-00	No Longer Available	1
37	698609	GASKET	1
38	000000-00	No Longer Available	1
49	864137	SCREW	1
52	000000-00	No Longer Available	1
53	000000-00	No Longer Available	1
53	868599	INTER PLT	1
55	000000-00	No Longer Available	1
57	000000-00	No Longer Available	1
83	692074	CHUCK PKG.	1
92	826226	KEY	1
109	000000-00	No Longer Available	1

Parts List for J-620 Type 4

Item Number	Part Number	Description	Qty Required
112	842610	SPRING-PRELOAD	1
112	694432	BEARING MOUNT	1
114	865643	SCREW	1
116	859384	SCREW	1
117	000000-00	No Longer Available	1
118	861434	CORD CLAMP	1
119	859227	SCREW	1
120	810716	RELIEVER	1
121	848741	WASHER	1
123	860756	SCREW	1
126	852714	SLINGER	1
128	000000-00	No Longer Available	1
128	694015	SCREW	1
135	691667	CHUCK SCREW	1
150	841644	SCREW	1
151	828841	LOCKNUT	1
152	905230	HOLDER-WRENCH	1
155	847564	SNAP RING	1
156	802851	O RING	1
157	859769	RET RING	1
158	802648	WASHER	1
160	861720	WASHER	1
161	000000-00	No Longer Available	1
800	801945	TUBE GREASE	1
800	874809	LUBRICANT-4LBS	1
800	801946	LUBE	1