


ISG-0522

7" Angle Grinder



Parts List

No.	Parts No.	Name of Parts	Qty
01	DG-70001	Motor Housing	1
02	PG-38043	Plug	1
03	DG-70049	Center Wheel Guard	1
04	DG-70S47	Flange	1
05	DG-70S45	Flange Nut	1
06	DG-70002	Seal Plate	1
07	BB-06292	Ball Bearing	1
08	BB-63032	Ball Bearing	1
09	DG-70007	Bevel Gear	1
10	DG-70S04	Arbor	1
11	WK-0516A	Woodruff Key	1
12	STW-015	External Stop Ring	1
13	WW-0016	Wave Washer	1
14	DG-70043	Exhaust Deflector	1
15	BB-62012	Ball Bearing	2
16	BB-62022	Ball Bearing	1
17	DG-70026	Bevel Pinion	1
18	HNI-03CB	Hex. Nut	2
19	DG-70022	Adjust Screw	1
20	STW-009	External Stop Ring	1
21	DG-70012	Front End Plate	1
22	DG-70014	Cylinder	1
23	DG-70016	Rotor Blade	4
24	DG-70011	Rotor	1
25	SP-30080	Spring Pin	2
26	DG-70017	Rear End Plate	1
28	B2-0520A	Hex Socket Head Cap Bolt	4
29	SW2-050A	Spring Washer	4
30	DG-70019	Pendulum	8
31	DG-70018	Governor	1
32	DG-70021	Plunger	1

No.	Parts No.	Name of Parts	Qty
33	B2-0510A	Hex Socket Head Cap Bolt	1
34	DG-70023	Spring	1
35	SP-30160	Spring Pin	2
36	VP-70047	Wrench	1
37	DG-70S54	L Shape Hex Wrench	1
38	HG-14005	L Shape Hex Wrench	1
40	DG-70050	Guard Clamp Plate	1
41	ORP-0040	O-Ring	2
46	DG-70028	Gasket	1
47	DG-70046	Grinding Wheel	1
48	S4-6020A	(+) Button Head Screw	2
50	AP-70047	Handle	1
51	S7-6030A	Flange Stop Screw	1
52	DG-70055	Throttle Valve Housing	1
53	DG-70063	Throttle Lever	1
54	SP-40250	Spring Pin	1
56	DG-70065	Lock Pin	1
57	DG-70057	Air Inlet Bushing	1
58	DG-40056	Throttle Housing	1
59	ORP-0100	O-Ring	1
60	DG-40055	Valve Spring	2
61	DG-40054	Valve Stem	1
62	ORP-0050	O-Ring	1
63	DG-70S10	Arbor Bearing Cap	1
64	ETWJ-040	E-Ring	1
65	DG-70056	Bushing	1
67	SS-0404A	Set Screw	1
69	DG-70S68	Adjust Nut	1

RPK-0522 Repair Kit: Contains part # 20,23,46,59,60,62

RBK-0522 Rebuild Kit: Contains part # 8,9,10,11,16,17