



Parts List for KG915K-BR Type 1

Item Number	Part Number	Description	Qty Required
1	569198-00	OUTER FLANGE	1
2	569200-00	INNER FLANGE	1
3	569202-00	SCREW	3
4	569203-00	FLANGE	1
5	569204-00	GUARD	1
6	5140040-52	SPINDLE	1
7	5140040-54	KEY	1
8	5140016-99	SPRING WASHER	1
9	569206-00	SCREW	4
10	5140040-55	GEARCASE COVER	1
11	5140040-56	BEARING	1
12	5140040-57	SELF TAPPING SCREW	3
13	5140040-58	GEAR	1
14	5140040-59	CIRCLIP	1
15	5140040-60	BEARING	1
16	5140040-61	CIRCLIP	1
17	569176-00	SIDE HANDLE	1
18	5140040-62	GEAR BOX	1
19	569209-00	SCREW	4
20	5140040-63	BUTTON	1
21	5140040-64	SPRING	1
22	569175-00	NUT	1
23	5140040-65	PINION	1
24	569167-00	BEARING	1
25	569168-00	BRUSH HOLDER PLATE	1
26	569170-00	SCREW	2
27	5140040-66	ARMATURE	1

Parts List for KG915K-BR Type 1

Item Number	Part Number	Description	Qty Required
28	5140040-68	BEARING	1
29	569171-00	COVER,BEARING	1
30	569172-00	BAFFLE	1
31	569173-00	SCREW	2
32	5140040-69	FIELD ASSY.	1
33	5140040-70	LEADWIRE	1
34	5140040-71	LEADWIRE	1
35	6010116-23	KNOB	1
36	6010116-31	FIELD CASE	1
37	187993-00	LABEL	1
38	569182-00	ROD	1
39	569181-00	SPRING	1
40	5140070-68	SWITCH	1
41	569196-00	SCREW	2
42	569195-00	CABLE CLAMP	1
43	569188-00	SCREW	4
44	569189-00	WASHER	4
45	5140040-73	BRUSH BOX	2
46	5140070-70	LABEL	1
47	596071-00	BRUSH	2
48	5140042-87	LEADWIRE	2
49	5140042-88	BELT	1
50	569194-00	PROTECTOR	1
51	6010116-19	REAR COVER	1
52	569178-00	SCREW	1
53	5140042-90	CORD & PLUG	1
54	569197-00	SPANNER WRENCH	1

Parts List for KG915K-BR Type 1

Item Number	Part Number	Description	Qty Required
57	5140070-72	ARMATURE ASSEMBLY	1
58	5140070-73	BRUSH BOX ASSY	1