



## Parts List for KS400-AR Type 2

Item Number	Part Number	Description	Qty Required
1	5140053-88	HOUSING	1
2	5140053-89	HOUSING COVER	1
3	5140053-90	FIELD 220V	1
4	5140053-92	ARMATURE	1
5	5140041-06	BLOCK	2
6	5140041-07	BRUSH,CARBON	2
7	5140041-09	BRUSH HOLDER	2
8	5140041-10	MIDDLE HOLDER	1
9	5140041-11	SCREW	1
10	5140041-12	WASHER	1
11	5140041-13	WASHER	1
12	5140041-14	PLATE	2
13	5140041-15	WASHER	1
14	5140041-16	GEAR	1
15	5140041-17	WASHER	1
16	5140041-18	E RING	1
17	5140041-19	ROLLER RING	1
18	5140041-20	SLIDE,BEARING	1
19	5140041-21	SHAFT ASSEMBLY	1
20	5140041-22	SCREW	1
21	5140053-94	GUARD	1
22	5140041-24	E RING	2
23	5140041-25	GUIDE WHEEL	1
24	5140041-26	SHAFT	1
25	5140041-27	SWITCH	1
26	5140041-29	CAPACITOR	1
27	5140041-30	WIRE,SUPPORT	1

## Parts List for KS400-AR Type 2

Item Number	Part Number	Description	Qty Required
28	5140041-31	PIN	2
29	5140041-32	CHUTE	2
30	5140041-33	NUT	2
31	5140041-34	PIN	1
32	5140041-35	GUIDE HOLDER	1
33	5140041-36	SHOE	1
34	5140041-37	PLATE	2
35	5140041-38	SCREW	2
36	5140041-39	LEAD WIRE	2
37	5140041-40	SCREW	2
38	5140041-41	CORD CLAMP	1
39	5140041-42	HEX WRENCH	1
40	5140041-45	CORD SET	1
41	5140041-46	CORD PROTECTOR	1
42	5140041-47	SCREW	8
43	5140041-48	BRAND LABEL	1
44	5140053-97	NAME PLATE	1
856	5140041-53	BLADE	1