



## Parts List for LHT120 Type 1

Item Number	Part Number	Description	Qty Required
1	90513370-01	GUARD	1
2	5103541-00	SCREW	8
3	574847-11	AUXILIARY HANDLE	1
4	574095-22	HANDLE CAP	1
5	90542557-01	BLADE & GEAR	1
6	90542265	WARNING,LABEL	1
7	571828-01	COVER GEAR HSG	1
8	90527921	BOLT	2
9	90526229	SPACER	7
10	90528235	SHEATH	1
11	371954-01	BLADE BOLT	7
12	90526227	FLANGED HEX NUT	7
14	311940-03	SCREW	2
17	571824-02	GEARBOX ASSY	1
18	370927-01	PLATE	1
19	5103555-00	SCREW	2
866	90587070	BATTERY PACK	1
867	90535852-02	BATTERY CAP	1
871	90553168	CHARGER	1