



## Parts List for LHT2436 Type 1

Item Number	Part Number	Description	Qty Required
1	90572710	GUARD	1
2	5103541-00	SCREW	13
3	90580427	AUXILIARY HANDLE	1
5	90568877	BLADE & GEAR	1
6	90573637	WARNING LABEL	1
7	90570808	SUPPORT PLATE	1
8	90527921	BOLT	2
9	376614-01	SPACER	2
10	90580554	SHEATH	1
11	098022-16	SCREW	8
12	148641-00	NUT,LOCK	8
14	90566914	SCREW	2
17	90564147	GEARBOX ASSY	1
18	90568498	PLATE	1
19	90577627	SCREW	2
20	90573657	NAME PLATE	1
866	90567304-02	BATTERY PACK	1
871	90567393-00	CHARGER	1