



## Parts List for LHT360C Type 1

Item Number	Part Number	Description	Qty Required
1	90632141	HOUSING & COVER	1
2	N507244	MOTOR & GEARCASE	1
3	90635255	BLADE & GEAR	1
4	90621626	BUTTON ACTUATOR	1
5	90623720	TORSION SPRING	1
6	376614-01	SPACER	2
7	90527921	BOLT	2
8	90570808	SUPPORT PLATE	1
9	90638012	GUARD ASSEMBLY	1
10	90577627	SCREW	2
11	90626002	AUXILIARY HANDLE	1
12	90632575	SWITCH ASSEMBLY	1
13	747329	SCREW	14
14	373158	SCREW	1
821	90636272	RATING LABEL	1
866	LBX1560	BATTERY	1
871	90642267	CHARGER	1
871	BDCAC60B	CHARGER	1