



LT10 Tractor UT-33012 - Control Panel, Battery And Gas Tank



Rendered by LeadVenture, Inc.

Ref #	Part #	Description	Qty	Context Note
1	JA375978	BOLT- 1/4-14	9	
2	JA400104	SCREW- 1/4-20 x 1/2 hex	2	
3	JA130412	SWITCH- Key	1	
4	JA409036	SCREW- #10 x 3/4	4	
5	JA343060	KEY	2	
6	JA992241	CONTROL	1	
7	JA158992	SWITCH- Headlight	1	
8	JA993102	PANEL- Dash	1	
9	JA990135	SWITCH- PTO	1	
10	JA992178	CONTROL TOWER ASSY.	1	
11	JA397379	TANK- Gas	1	
12	JA376011	CAP- Fuel	1	
13	JA990980	STRAP- Gas tank	1	
14	JA361117	BUSHING	1	
15	JA991072	VALVE- Shut off	1	
16	JA991073	TUBING- Rubber	1	(fuel line)
17	JA339601	SUPPORT	1	
18	JA991470	DECAL- Battery	1	
19	JA376068	COVER- Battery	1	
20	JA339605	BRACKET	1	
21	JA352496	CLIP	2	
22	JA158959	STRAP- Hold down	1	
23	JA376080	BATTERY	1	
24	JA995590	SOLENOID	1	
25	JA446130	WASHER- Lock 1/4	4	
26	JA443102	NUT- Hex 1/4-20	2	
27	JA443802	NUT- 1/4-20	2	
28	JA444306	NUT- Hex 8-32	2	
29	JA446112	WASHER- Lock #8	1	
30	JA403910	SCREW- 10-24 x 1/2	2	
31	JA452002	WASHER- Plain 1/4"	2	
32	JA444782	NUT- Hex Centerlock 10-24	2	
33	JA992224	DECAL- Throttle	1	
34	00305	DECAL- Gasohol	1	
35	JA993043	DECAL- Instruction	1	
	JA473165	SECURE TIES	A/R	

LT10 Tractor UT-33012 - Cowlings, Rear Fender And Seat Assembly




Rendered by LeadVenture, Inc.

Ref #	Part #	Description	Qty	Context Note
1	JA376122	WASHER- Insulation	2	
2	JA376118	SPRING- Compression	2	
3	JA376116	CONTACT- Interlock	1	
4	JA444310	NUT- Hex 10-24	5	
5	JA376117	PIN- Seat Support	2	
6	JA403908	SCREW- 10-24 x 3/8	7	
7	JA335757	REFLECTOR- Reflex	2	
8	JA 400182	SCREW- Hex hd. 5/16-18 x 5/8	4	
9	JA409254	SCREW- #10 x 1/2	4	
10	JA375978	BOLT- 1/4-14 x .44	4	
11	JA400108	USE 80052	5	
12	JA446136	WASHER- Lock 5/16	6	
13	JA453009	WASHER- 5/16	4	
14	JA991241	PAN- Seat	1	
15	JA124072	SEAT- Jacobsen	1	
16	JA990290	LATCH	2	
17	JA446130	WASHER- Lock 1/4	1	
18	JA376120	BRACKET- Hitch	1	
19	JA376119	ROD- Hinge	2	
20	JA991191	FENDER	1	
21	JA453002	WASHER	2	
22	JA991321	HOOD	1	
23	JA408406	SCREW- 1/4 x 14 x 1	6	
24	JA339626	RETAINER- Light	2	
25	JA376091	LIGHT- Head	2	
26	JA408404	SCREW- Tap hex 1/4-14 x 3/4	2	
27	JA994470	CLIP	2	
28	JA408405	SCREW- 1/4-14 x 1/2	2	
29	JA993343	PANEL- Side R.H.	1	Incl. #6, 46 & 47
	JA993345	PANEL- Side L.H.	1	
30	JA446118	WASHER- Lock #10	2	
31	JA991014	DECAL- Hi-Lift Pos.	1	
32	JA400188	BOLT- Hex 5/16-18 x 1	2	
33	JA339612	PAD- Footboard	2	
34	JA443102	NUT- Hex 1/4-20	4	
35	JA453023	WASHER- Plain 1/4	4	
36	JA339627	BRACKET- Footboard	1	
37	JA443106	NUT- Hex 5/16-18	2	
38	JA441604	BOLT- 1/4-20 x 1	4	
39	JA991301	FOOTBOARD, R.H.	1	Includes Item #33
	JA991271	FOOTBOARD L.H.	1	Includes item #33

Ref #	Part #	Description	Qty	Context Note
40	JA446128	WASHER- Lock 1/4	4	
41	JA991291	COWLING	1	
42	JA392600	HINGE- Grille	1	
43	JA400106	SCREW- 1/4-20 x 5/8	1	
44	JA990397	GRILLE SCREEN	1	
45	JA991017	DECAL- Lo-Lift Pos.	1	
46	JA464842	RIVET- Plain	4	
47	JA457005	WASHER- Flat	4	

LT10 Tractor UT-33012 - Frame Transaxle And Engine




Rendered by LeadVenture, Inc.

Ref #	Part #	Description	Qty	Context Note
1	JA446142	WASHER- 3/8 lock	6	
2	JA 443110	NUT- 3/8-16 hex	6	
3	JA392590	BRACKET- Hitch	1	
4	JA408865	BOLT- 1/4-20 x 9/16	6	
5	JA460014	PIN - Cotter 3/32 x 3/4	4	
6	JA376077	SPACER- Lever	1	
7	JA339611	ROD- Hi-lo sect.	1	
8	JA339593	LEVER- Hi-lo	1	
9	JA315209	KNOB	1	
10	JA453009	WASHER- Flat 5/16	A/ R	
11	JA400186	SCREW- 5/16-18 x 7/8 hex hd. cap	2	
12	JA990590	DECAL- Second & Reverse	1	
13	JA376078	KNOB- Shift lever	1	
14	JA990600	DECAL- First & Third	1	
15	JA990260	DECAL- Warning	1	
16	JA376066	BUSHING- Snap	1	
17	JA 400194	SCREW- 5/16-18 x 1 3/4 hex hd. cap	4	
18	JA991071	PULLEY- Drive	1	
19	JA991910	CABLE- Retaining	1	
20	JA443106	NUT- 5/16-18	5	
21	JA339569	DECAL- Warning	1	
22	JA117790	FRAME ASSY.	1	
23	JA376038	GUIDE- Front belt	1	
24	JA392593	PULLEY- Drive	1	
25	JA570047	WASHER	1	
26	JA325288	KEY	1	
27	JA991059	BRAKE- Electric clutch	1	
28	JA446148	WASHER- Lock 7/16 hvy.	1	
29	JA400384	SCREW- 7/16-20 x 2 3/4 hex hd. cap	1	
30	JA990128	CLUTCH- Retainer	1	
31	JA392594	BELT- Traction drive	1	
32	JA444718	NLA(NO LONGER AVAILABLE)	4	
33	JA339630	IDLER- Inside	1	
34	JA400268	SCREW- 3/8-16 x 1 3/4 hex hd. cap	1	

Ref #	Part #	Description	Qty	Context Note
35	JA460048	PIN- Cotter 3/16 x 1	1	
36	JA453017	NLA(NO LONGER AVAILABLE)	1	
37	JA328133	BUSHING	2	
38	JA376098	ROD- Idler actuator	1	
39	JA376088	SPRING- Extension	1	
40	JA376037	GUIDE- Rear belt	1	
41	JA990580	DECAL- Hi-Lo	1	
42	JA 400182	SCREW- 5/16-18 x 5/8 hex hd. cap	1	
43	JA463017	KEY- 3/16 x 3/4	1	
44	JA142190	CLUTCH BEARING ASSY.	1	
45	JA336222	IDLER- Backside	1	
46	JA446136	WASHER- Lock 5/16 hvy.	2	
47	JA376017	BRACKET	1	
48	JA409812	SCREW- 5/16-18 x 3/4	2	
49	JA181963	REAR WHEEL ASSY.	2	
50	JA458419	RING- Retaining	2	
51	JA376090	HUB CAP- Rear wheel	2	
52	JA310611	KEY- 3/16 x 3/16 x 2 1/2	2	
53	JA313820	SPACER	A/ R	
54	JA376079	SPACER- Rear wheel	2	
55	JA453022	WASHER- Flat 13/16	2	
56	JA400286	SCREW- Hex 3/8-16 x 2 3/4	4	
57	JA993015	TRANSAXLE- 6 Speed	1	
58	JA458009	RING- Retaining	1	
		ENGINE- 8 HP (LTX-8)	1	When ordering engine parts, see your local Briggs & Stratton dealer.
		ENGINE- 12 HP (LTX-12)	1	When ordering engine parts, see your local Briggs & Stratton dealer.

LT10 Tractor UT-33012 - Lift, Brake And Clutch Linkage




Rendered by LeadVenture, Inc.

Ref #	Part #	Description	Qty	Context Note
1	JA343497	KNOB- Implement lift handle	1	
2	JA142186	HANDLE- Lift	1	
3	JA181962	LIFT HANDLE BRACKET & ROD ASSY.	1	
4	JA 443110	NUT- Hex 3/8-16	4	
5	JA446142	WASHER- Lock 3/8 hvy.	4	
6	JA461347	PIN- Groove 5/16 x 2 1/4	1	
7	JA351587	BUSHING- Flange	4	
8	JA452006	NLA(NO LONGER AVAILABLE)	2	
9	JA376092	SPRING- Compression	1	
10	JA444718	NLA(NO LONGER AVAILABLE)	1	
11	JA461383	PIN- Spring 3/16 x 1	1	
12	JA315209	KNOB- Parking brake	1	
13	JA376086	ROD- Brake lock	1	
14	JA315344	SPRING- Compression	1	
15	JA453009	WASHER- Flat 5/16	8	
16	JA460026	PIN- Cotter 1/8 x 3/4	2	
17	JA460014	PIN- Cotter 3/32 x 3/4	9	
18	JA309902	BUSHING- Pivot	2	
19	JA461383	PIN- Roll 3/16 x 1	2	
20	JA375978	BOLT- 1/4-14	2	
21	JA376061	BRACKET- Safety switch	1	
22	JA991560	SWITCH- Safety	1	(traction clutch)
23	JA402776	SCREW #4-40 x 1.00 slotted truss head	2	
24	84011	WASHER- Flat 4-40 x 1/4	2	
25	JA446102	WASHER- Lock #4 Reg.	2	
26	JA444302	NUT #4-40 hex	2	
27	JA376073	PULLEY- Lift cable	2	
28	JA376015	RETAINER- Lift cable	2	
29	JA344895	PEDAL- Clutch	1	
30	JA376106	PEDAL- Safety stop clutch	1	
31	JA375810	NUT- 5/8 push on	1	
32	JA339618	ROD- Clutch	1	
33	JA376094	BOLT- Shoulder	4	
34	JA124134	DRAG LINK ASSY.	1	
35	JA461451	PIN- Clevis	2	
36	JA376063	YOKE	2	
37	JA339600	CABLE- Deck lift	2	
38	JA434027	SCREW- 10-24 x 1 3/4	1	
39	JA142200	CLUTCH ROD ACTUATOR ASSY.	1	
40	JA443808	NUT- 5/16-24 hex jam	2	
41	JA375431	BOLT- Idler pivot	1	
42	JA992567	LATCH- Parking brake	1	
43	JA443106	NUT- 5/16-18 hex	3	
44	JA142185	REAR LIFT BAR ASSY.	1	
45	JA376099	ROD- Brake	1	

Ref #	Part #	Description	Qty	Context Note
46	JA181969	BRAKE SPRING BRACKET ASSY.	1	
47	JA376102	SPRING- Brake compression	1	
48	JA181965	REAR LIFT & BUSHING ASSY.	1	
49	JA446136	WASHER- Lock 5/16 hvy.	1	
50	JA461363	PIN- Roll	1	
51	JA444782	NUT- Centerlock #10-24	1	

LT10 Tractor UT-33012 - Steering Linkage




Rendered by Lead/Venture, Inc.

Ref #	Part #	Description	Qty	Context	Note
1	JA339631	ARM- Pitman	1		
2	JA311555	BUSHING	2		
3	JA443826	NUT- 5/8	1		
4	JA376121	SPACER- Bearing	1		
5	JA465006	BALL-.312 dia.	1		
6	JA376108	SPACER- Steering	1		
7	JA461383	PIN- Roll 3/16 x 1	1		
8	JA339632	SHAFT- Steering wheel	1		
9	JA443102	NUT- Hex 1/4-26	2		
10	JA446130	WASHER- Lock 1/4	2		
11	JA400104	SCREW- Hex 1/4-20 x 1/2	2		
12	JA461387	PIN- Roll 1/4-1	1		
13	JA990346	WHEEL- Steering	1		
14	JA376074	BEARING- Steering shaft	1		
15	JA346133	BUSHING	1		
16	JA375970	WASHER	1		
17	JA339629	PINION- Steering	1		
18	JA992581	WASHER	5		
19	JA 443110	NUT- Hex 3/8-16	4		
20	JA392599	STEERING- Gear	1		
21	JA142203	SUPPORT- Steering	1		
22	JA 443118	NUT- Hex 1/2-13	1		
23	JA446154	WASHER- Lock 1/2	1		
24	JA453017	NLA(NO LONGER AVAILABLE)	1		
25	JA400276	SCREW- Hex 3/8-16 x 2	1		
26	JA376067	ROD	1		
27	JA453022	WASHER- Flat 3/4	6		
28	JA461408	PIN- Roll 1/4 x 1 1/2	1		
29	JA376065	BUSHING- Spindle	4		
30	JA408878	SCREW- 1/4-20 x 3/4	1		
31	JA453023	WASHER- Plain 1/4	1		
32	JA460064	PIN- Cotter	1		
33	JA142168	FRONT AXLE ASSY.	1		
34	JA990937	SPINDLE	1		
35	JA310084	BEARING	2		
36	JA400272	SCREW- Hex 3/8-16 x 2 1/4	1		
37	JA376059	BAR- Tie	1		
38	JA992617	SPINDLE- R.H.	1		
39	JA376085	BOLT- Tie bar mounting	2		
40	JA446142	WASHER- 3/8 lock	5		
41	JA 444762	NUT- Centerlock 3/8-16	1		

Ref #	Part #	Description	Qty	Context	Note
42	JA320790	KEY- 3/16 x 1 1/2	1		
43	JA376114	SPACER- Bell joint	1		
44	JA376064	BALL JOINT	1		
45	JA400268	SCREW- Hex 3/8 x 16 x 1 3/4	3		
46	JA443106	NUT- Hex 5/16-18	4		
47	JA446136	WASHER- Lock 5/16	3		
48	JA453009	WASHER- 5/16	6		
49	JA400186	SCREW- Hex 5/16-18 x 7/8	3		
50	JA443112	NUT- Hex 3/8-24	3		
51	JA376062	TUBE	1		
52	JA376060	BALL JOINT	1		
53	JA181964	RIM & TIRE ASSY.	2		
54	JA375970	WASHER	1		
55	JA312398	WASHER-HT	2		
56	JA460040	PIN- Cotter 5/32 x 1 1/4	2		
57	JA316802	CAP	2		
58	JA313820	SPACER	8		
59	JA471225	FITTING- Grease	2		
60	JA376115	SPACER- Ball joint	1		
61	JA992368	ARM- Steering	1		
62	JA990345	CAP- Steering wheel	1		
63	JA375411	WASHER- Dust	2		

LT10 Tractor UT-33012 - Wiring Diagram



Rendered by LeadVenture, Inc.

Ref #	Part #	Description	Qty	Context	Note
	JA993030	HARNESS, Taillights			
	JA990890	HARNESS, Headlights			
	JA990162	HARNESS, Rectifier			
	JA990134	HARNESS, Main wiring			