


LT1238G Tractor UT-33021 - 38" Rotary Mower Attachment Deck




Rendered by LeadVenture, Inc.

Ref #	Part #	Description	Qty	Context Note
1	JA995045	NUT-Center Lock (9/16-18)	2	
2	JA994942	PULLEY- Cutter head	2	
3	JA455049	WASHER- Flat	6	
4	JA994931	SPINDLE- Cutter head	2	
5	JA994934	SPACER- Spindle	2	
6	JA990007	PLATE- Air cut off	2	
7	JA453011	WASHER- Flat (3/8")	8	
8	JA445775	NUT- Flange (5/16-18)	6	
9	JA441676	BOLT- Rd. hd., sq. neck (3/8-16 x 1 1/4")	4	
10	JA441679	BOLT- Rd. hd., sq. neck	6	
11	JA994930	ROD- Deflector	1	
12	JA990006	BRACKET- Chute hinge	1	
13	JA994932	SPRING- Torsion	1	
14	JA994939	CHUTE- Deflector Assy.	1	
15	JA994935	NUT- Pal, push (3/8")	2	
16	JA995046	NUT- Hex (9/16-18)	2	
17	JA994928	WASHER- Flat	2	
18	JA994927	WASHER- Belleville	2	
19	JA994978	BLADE	2	
20	JA994933	BLADE- Adaptor	2	
21	JA994941	HOUSING- Spindle	2	
22	JA994945	DECK ASSEMBLY	1	Includes items 23-25
23	JA339460	DECAL- Danger	2	
24	JA339566	DECAL- No step		
25	JA994954	DECAL- Belt installation	1	
26	JA314916	WASHER- Flat	4	
27	JA 444762	NUT- Hex lock (3/8-16)	9	
28	JA309457	WASHER- Blade mtg.	4	
29	JA994913	ARM- Idler	1	
30	JA400266	SCREW- Hex hd., cap (3/8-16 x 1 1/2")		
31	JA990824	PULLEY- Idler	2	
32	JA994974	SPRING- Extension	1	
33	JA400268	SCREW- Hex hd., cap (3/8-16 x 1 3/4")	1	
34	JA400270	SCREW- Hex hd., cap (3/8-16 x 2")	1	
35	JA376144	ROD- Spring release	1	
36	JA352594	SPACER- Idler arm	1	
37	JA995051	SCREW- Hex washer hd.	10	
38	JA992514	BRACKET- Rear hanger	2	
39	JA376094	BOLT- Shoulder	2	
40	JA991759	PIN- Clevis	2	
41	JA994915	PIN- Link	1	

Ref #	Part #	Description	Qty	Context Note
42	JA994972	BRACKET- Link	1	
43	JA460306	PIN- Hair cotter	3	
44	JA453023	WASHER- Flat	2	


LT1238G Tractor UT-33021 - Control Panel, Battery And Gas Tank



Rendered by LeadVenture, Inc.

Ref #	Part #	Description	Qty	Context Note
1	JA375978	BOLT- (1/4-14 x .44)	10	
2	JA400104	SCREW- Hex (1/4-20 x 1/2")	2	
3	JA130412	SWITCH- Key	1	
4	JA409036	SCREW- (#10 x 3/4")	4	
5	JA343060	KEY	2	
6	JA992241	CONTROL- Throttle	1	
7	JA158992	SWITCH- Headlight	1	
8	JA993102	PANEL- Dash	1	
9	JA990135	SWITCH- PTO	1	
10	JA994344	CONTROL TOWER ASSY.	1	
11	JA994982	TANK-Gas	1	
12	JA376011	CAP- Fuel	1	
13	JA990980	STRAP- Gas tank	1	
14	JA361117	BUSHING	1	
15	JA994981	VALVE- Shut off	1	
16	JA994979	TUBING- Rubber (fuel line)	2	
17	JA339601	SUPPORT	1	
18	JA991470	DECAL- Battery	1	
19	JA447012	WASHER- External tooth (1/4")	1	
20	JA339605	BRACKET	1	
21	JA352496	CLIP	2	
22	JA158959	STRAP- Hold down	1	
23	JA376080	BATTERY	1	
24	JA995590	SOLENOID	1	
25	JA446130	WASHER- Lock (1/4")	4	
26	JA443102	NUT- Hex (1/4-20)	4	
27	JA443802	NUT- (1/4-20)	2	
28	JA444306	NUT- Hex (8-32)	2	
29	JA446112	WASHER- Lock (#8)	1	
30	JA403910	SCREW- (10-24 x 1/2")	2	
31	JA452002	WASHER- Plain (1/4")	2	
32	JA444782	NUT- Hex Centerlock (10-24)	2	
33	JA992224	DECAL- Throttle	1	
34	JA400110	BOLT- (1/4-20 x 7/8")	1	
35	JA993043	DECAL- Instruction	1	
	JA473165	SECURE TIES	A/R	
36	JA994980	ELBOW	1	

LT1238G Tractor UT-33021 - Cowlings, Rear Fender And Seat Assembly




Rendered by LeadVenture, Inc.

Ref #	Part #	Description	Qty	Context Note
1	JA376122	WASHER- Insulation	2	
2	JA376118	SPRING- Compression	2	
3	JA376116	CONTACT- Interlock	1	
4	JA444310	NUT Hex (10-24)	5	
5	JA376117	PIN- Seat Support	2	
6	JA403908	SCREW- (10-24 x 3/8")	10	
7	JA335757	REFLECTOR- Tail light	2	
8	JA 400182	SCREW- Hex hd. (5/16-18 x 5/8")	4	
9	JA409254	SCREW- (#10 x 1/2")	4	
10	JA375978	BOLT- (1/4-14 x .44)	4	
11	JA400108	USE 80052	5	
12	JA446136	WASHER- Lock (5/16")	6	
13	JA453009	WASHER- (5/16")	4	
14	JA994925	PAN- Seat	1	
15	JA994887	SEAT	1	
16	JA990290	LATCH	2	
17	JA446130	WASHER- Lock (1/4")	1	
18	JA376120	BRACKET- Hitch	1	
19	JA376119	ROD- Hinge	2	
20	JA994923	FENDER	1	
21	JA452002	WASHER	2	
22	JA994835	HOOD	1	
23	JA408406	SCREW- (1/4 x 14 x 1")	6	
24	JA339626	RETAINER- Light	2	
25	JA376091	LIGHT- Head	2	
26	JA408404	SCREW- Tap hex (1/4-14 x 3/4")	2	
27	JA994470	CLIP	2	
28	JA408405	SCREW- (1/4-14 x 1/2")	2	
29	JA993343	PANEL- Side R.H.	1	Incl. #6, 46 & 47
	JA993345	PANEL- Side L.H.	1	
30	JA446118	WASHER- Lock (#10)	2	
31	JA991014	DECAL- Hi-Lift Pos.	1	
32	JA400188	BOLT- Hex (5/16-18 x 1")	2	
33	JA339612	PAD- Footboard	2	
34	JA443102	NUT- Hex (1/4-20)	4	
35	JA453023	WASHER- Plain (1/4")	16	
36	JA339627	BRACKET- Footboard	1	
37	JA443106	NUT- Hex (5/16-18)	2	
38	JA441604	BOLT- (1/4-20 x 1")	4	
39	JA994921	FOOTBOARD, R.H.	1	Includes item #33
	JA994922	FOOTBOARD L.H.	1	Includes item #33

Ref #	Part #	Description	Qty	Context Note
40	JA446128	WASHER- Lock (1/4")	5	
41	JA994924	COWLING	1	
42	JA392600	HINGE- Grille	1	
43	JA400110	SCREW- (1/4-20 x 7/8")	1	
44	JA990397	GRILLE SCREEN	1	
45	JA991017	DECAL- Lo-Lift Pos.	1	
46	JA464842	RIVET- Plain	4	
47	JA457005	WASHER- Flat	6	
48	JA446128	WASHER- Lock (1/4")	1	

LT1238G Tractor UT-33021 - Frame Transaxle And Engine




Rendered by LeadVenture, Inc.

Ref #	Part #	Description	Qty	Context Note
1	JA446142	WASHER- Lock (3/8")	6	
2	JA 443110	NUT- Hex (3/8-16)	6	
3	JA994985	BRACKET- Hitch	1	
4	JA408865	BOLT- (1/4-20 x 9/16")	2	
5	JA460014	PIN- Cotter (3/32 x 3/4")	4	
6	JA376077	SPACER- Lever	1	
7	JA339611	ROD- Hi-lo sect.	1	
8	JA339593	LEVER- Hi-lo	1	
9	JA315209	KNOB	1	
10	JA453009	WASHER- Flat (5/16")	A/ R	
11	JA400186	SCREW- Hex hd. cap (5/16-18 x 7/8")	2	
12	JA990590	DECAL- Second & Reverse	1	
13	JA376078	KNOB- Shift lever	1	
14	JA990600	DECAL- First & Third	1	
15	JA990260	DECAL- Warning	1	
16	JA376066	BUSHING- Snap	1	
17	JA 400194	SCREW- Hex hd. cap (5/16-18 x 1 3/4")	4	
18	JA991071	PULLEY- Drive	1	
19	JA994960	CHAIN- Restraining	1	
20	JA443106	NUT- (5/16-18)	5	
21	JA992354	DECAL- Warning	1	
22	JA117790	FRAME ASSY.	1	
23	JA376038	GUIDE- Front belt	1	
24	JA392593	PULLEY- Drive	1	
25	JA454012	WASHER- Shakeproof	1	
26	JA306968	KEY	2	
27	JA990977	BRAKE- Electric clutch	1	
28	JA446148	WASHER- Lock hvy. (7/16")	1	
29	JA400368	SCREW- Hex hd. cap (7/16-20 x 3")	1	
30	JA990128	CLUTCH- Retainer	1	
31	JA392594	BELT- Traction drive	1	
32	JA444718	NLA(NO LONGER AVAILABLE)	4	
33	JA339630	IDLER- Inside	1	
34	JA400268	SCREW- Hex hd cap (3/8-16 x 1 3/4")	2	

Ref #	Part #	Description	Qty	Context Note
35	JA460048	PIN- Cotter (3/16 x 1")	1	
36	JA453017	NLA(NO LONGER AVAILABLE)	1	
37	JA328133	BUSHING	2	
38	JA376098	ROD- Idler actuator	1	
39	JA376088	SPRING- Extension	1	
40	JA376037	GUIDE- Rear belt	1	
41	JA990580	DECAL- Hi-Lo	1	
42	JA 400182	SCREW- Hex hd. cap (5/16-18 x 5/8")	1	
43	JA463017	KEY- (3/16 x 3/4")	1	
44	JA994338	CLUTCH BEARING ASSY.	1	
45	JA336222	IDLER- Backside	1	
46	JA446136	WASHER- Lock hvy. (5/16")	2	
47	JA376017	BRACKET	1	
48	JA409812	SCREW- (5/16-18 x 3/4")	2	
49	JA181963	REAR WHEEL ASSY.	2	
50	JA458419	RING- Retaining	2	
51	JA376090	HUB CAP- Rear wheel	2	
52	JA310611	KEY- (3/16 x 3/16 x 2 1/2")	2	
53	JA313820	SPACER	A/ R	
54	JA376079	SPACER- Rear wheel	2	
55	JA453022	WASHER- Flat (13/16")	2	
56	JA400286	SCREW- Hex (3/8-16 x 2 3/4")	4	
57	JA993015	TRANSAXLE- 6 Speed	1	
58	JA458009	RING- Retaining	1	
		ENGINE- 12 HP		When ordering engine parts, see your local Briggs & Stratton dealer.


LT1238G Tractor UT-33021 - Lift, Brake And Clutch Linkage



Ref #	Part #	Description	Qty	Context Note
1	JA343497	KNOB- Implement lift handle	1	
2	JA994334	HANDLE- Lift	1	
3	JA181962	LIFT HANDLE BRACKET & ROD ASSY	1	
4	JA 443110	NUT- Hex (3/8-16)	2	
5	JA446142	WASHER- Lock hvy (3/8")	2	
6	JA461347	PIN- Groove (5/16 x 2 1/4")	1	
7	JA351587	BUSHING- Flange	4	
8	JA452006	NLA(NO LONGER AVAILABLE)	2	
9	JA376092	SPRING- Compression	1	
10	JA444718	NLA(NO LONGER AVAILABLE)	1	
11	JA461383	PIN- Spring (3/16 x 1")	1	
12	JA315209	KNOB- Parking brake	1	
13	JA376086	ROD- Brake lock	1	
14	JA315344	SPRING- Compression	1	
15	JA453009	WASHER- Flat (5/16")	8	
16	JA460026	PIN- Cotter (1/8 x 3/4")	2	
17	JA460014	PIN- Cotter (3/32 x 3/4")	7	
18	JA309902	BUSHING- Pivot	2	
19	JA461383	PIN- Roll (3/16 x 1")	2	
20	JA375978	BOLT- (1/4-14 x .44)	2	
21	JA376061	BRACKET- Safety switch	1	
22	JA991560	SWITCH- Safety	1	(traction clutch)
23	JA402776	SCREW- Slotted truss head (#4-40 x 1.00)	2	
24	JA455057	WASHER- Flat (#4)	2	
25	JA446102	WASHER- Lock Reg (#4)	2	
26	JA444302	NUT- Hex (#4-40)	2	
27	JA376073	PULLEY- Lift cable	2	
28	JA376015	RETAINER- Lift cable	2	
29	JA344895	PEDAL- Clutch	1	
30	JA992554	TUBE- Cable cover	2	
31	JA375810	NUT- Push on (5/8")	1	
32	JA339618	ROD- Clutch	1	
33	JA376094	BOLT- Shoulder	4	
34	JA444782	NUT- Ctr lock (#10-24)	1	
35	JA461363	PIN- Roll	1	
36	JA446136	WASHER- Lock hvy. (5/16")	1	
37	JA339600	CABLE- Deck lift	2	
38	JA434027	SCREW- (10-24 x 1 3/4")	1	
39	JA142200	CLUTCH ROD ACTUATOR ASSY.	1	
40	JA181965	REAR LIFT & BUSHING ASSY.	1	
41	JA375431	BOLT- Idler pivot	1	
42	JA992567	LATCH- Parking brake	1	
43	JA443106	NUT- Hex (5/16-18)	3	
44	JA142185	REAR LIFT BAR ASSY	1	
45	JA376099	ROD- Brake	1	

Ref #	Part #	Description	Qty	Context Note
46	JA994346	BRAKE SPRING BRACKET ASSY.	1	
47	JA376102	SPRING- Brake compression	1	


LT1238G Tractor UT-33021 - Steering Linkage



Ref #	Part #	Description	Qty	Context Note
1	JA994336	ARM- Pitman	1	
2	JA311555	BUSHING	2	
3	JA443826	NUT- (5/8")	1	
4	JA376121	SPACER- Bearing	1	
5	JA465006	BALL- (.312 dia)	1	
6	JA376108	SPACER- Steering	1	
7	JA461383	PIN- Roll (3/16 x 1")	1	
8	JA994335	SHAFT- Steering wheel	1	
9	JA443102	NUT- Hex (1/4-20)	3	
10	JA446130	WASHER- Lock (1/4")	2	
11	JA400104	SCREW- Hex (1/4-20 x 1/2")	2	
12	JA461387	PIN- Roll (1/4 x 1")	1	
13	JA990346	WHEEL- Steering	1	
14	JA376074	BEARING- Steering shaft	1	
15	JA346133	BUSHING	1	
16	JA375970	WASHER	1	
17	JA339629	PINION- Steering	1	
18	JA992581	WASHER	3	
19	JA 443110	NUT- Hex (3/8-16)	3	
20	JA392599	GEAR- Steering	1	
21	JA994337	SUPPORT- Steering	1	
22	JA 443118	NUT- Hex (1/2-13)	1	
23	JA446154	WASHER- Lock (1/2")	1	
24	JA453017	NLA(NO LONGER AVAILABLE)	1	
25	JA375411	WASHER- Dust	2	
26	JA376067	ROD	1	
27	JA453022	WASHER- Flat (3/4")	6	
28	JA461408	PIN- Roll (1/4 x 1 1/2")	1	
29	JA376065	BUSHING- Spindle	4	
30	JA400110	SCREW- (1/4-20 x 7/8")	1	
31	JA453023	WASHER- Plain (1/4")	1	
32	JA460064	PIN- Cotter	1	
33	JA994339	FRONT AXLE ASSY	1	
34	JA990937	SPINDLE	1	
35	JA310084	BEARING	2	
36	JA400272	SCREW- Hex (3/8-16 x 2 1/4")	1	
37	JA376059	BAR- Tie	1	
38	JA992617	SPINDLE- R.H.	1	
39	JA376085	BOLT- Tie bar mounting	2	
40	JA446142	WASHER- Lock (3/8")	5	
41	JA 444762	NUT- Centerlock (3/8-16)	1	

Ref #	Part #	Description	Qty	Context	Note
42	JA320790	KEY- (3/16 x 1 1/2")	1		
43	JA376114	SPACER- Ball joint	1		
44	JA992252	SCREW- (3/8-16 x 1 1/2")	1		
45	JA400268	SCREW- Hex (3/8 x 16 x 1 3/4")	1		
46	JA443106	NUT- Hex (5/16-18)	4		
47	JA446136	WASHER- Lock (5/16")	3		
48	JA453009	WASHER- (5/16")	6		
49	JA400186	SCREW- Hex (5/16-18 x 7/8")	3		
50	JA443112	NUT- Hex (3/8-24)	3		
51	JA376062	TUBE	1		
52	JA376060	BALL JOINT	1		
53	JA181964	RIM & TIRE ASSY	2		
54	JA375970	WASHER	1		
55	JA312398	WASHER-HT	2		
56	JA460040	PIN- Cotter (5/32 x 1 1/4")	2		
57	JA316802	CAP	2		
58	JA313820	SPACER	8		
59	JA471225	FITTING- Grease	2		
60	JA376115	SPACER- Ball joint	2		
61	JA994342	ARM- Steering	1		
62	JA990345	CAP- Steering wheel	1		
63	JA375411	WASHER- Dust	2		

LT1238G Tractor UT-33021 - Wiring Diagram



Ref #	Part #	Description	Qty	Context	Note
1	JA376124	CABLE- BAT TO GND	1		
2	JA994377	HARNESS, MAIN	1		
3	JA990890	HARNESS, HEAD LTS	1		
4	JA993030	HARNESS, TAIL LTS	1		