



MP88 Multi Purpose Saw UT-05051-B 05051-B-UT MP88 Multi Purpose Saw UT-05051-B MP88 Multi Purpose Saw - Carburetor - Air Cleaner



Rendered by LeadVenture, Inc.

Ref #	Part #	Description	Qty
1	82527	SCREW-Hex Cap (10-14 x 2")	2
2	496732	SHIELD-Carburetor	1
3	49671	GASKET-Carburetor Shield	1
4	PS97295	GROMMET	2
5	A49510A	CARBURETOR	1
6	A972902A	ADAPTER-Carburetor	1
7	96620	SCREW-Torx Truss (10-24 x 1/2")	2
8	PS97291	GASKET-Carburetor	1
9	PS97298	GASKET-Carb. Chamber	1
10	49509A	COVER-Carb. Chamber	1
11	80582	SCREW-Pan Hd. (8-32 x 5/8")	4
12	49511A	BOLT	1
13	49555	FILTER-Air	1
14	94150	"O" Ring	2
15	49513	FELT PREFILTER	1
16	49512	ELEMENT-Air Filter	1
17	498981	AIR FILTER ELEMENT COVER	1
18	81162	NUT-Hex (5/16-18)	1
19	A49514A	FILTER COVER	1
20	06365	KNOB	1
21	46072	RETAINING RING	1
NOTE1	A03611A	FOAM KIT	


MP88 Multi Purpose Saw UT-05051-B 05051-B-UT MP88 Multi Purpose Saw UT-05051-B MP88 Multi Purpose Saw
- Clutch - Crankcase



Rendered by LeadVenture, Inc.

Ref #	Part #	Description	Qty
1	88041	SCREW-Hex Sems (8-32 x 3/4")	3
2	93628	CLUTCH COVER	1
3	A93632B	CLUTCH SHOE	3
4	93638A	CLUTCH SPRING	3
5	93639	CLUTCH SPIDER	1
6	93650	WASHER-Thrust	1
7	A49543	PULLEY & DRUM	1
8	46071	NEEDLE BEARING	1
9	46070	RACE-Inner	1
10	46135	WASHER-Thrust	1
11	A08391	CRANKCASE ASSY. (COMPLETE)	1
12	A49537A	RETAINING-Bearing	1
13	12306	SEAL	1
14	82293	SCREW-Socket Cap (10-24 x 5/8")	3
15	00191D	GASKET	1
16	82595	WHEEL ARM BOLT (5-16-18 x 2.5")	2
	81208	NUT-Hex Lock (10-24)	4
	12689A	RETAINER-Nut	2
	58308B	SEAL-Shaft	1
NOTE1	A03611A	FOAM KIT	


MP88 Multi Purpose Saw UT-05051-B 05051-B-UT MP88 Multi Purpose Saw UT-05051-B MP88 Multi Purpose Saw -
Engine Housing



Rendered by LeadVenture, Inc.


Ref #	Part #	Description	Qty
1	A49770A	HOUSING-Engine	1
2	93410A	TANK VENT FILTER	2
3	96841	VALVE-Duck Bill	1
4	96620	SCREW-Torx Truss (10-24 x 1/2")	2
5	972902A	ADAPTOR-Carburetor	1
6	PS97291	GASKET-Carburetor	1
7	9311237	TUBING-Rubber (Fuel Line, 9 1/2")	1
8	9315723	TUBING-Rubber (Pulse Line, 6 1/2")	1
9	93385A	TRIGGER-Lock	1
10	PS97265	SPRING-Flat	1
11	972921	ROD-Choke	1
12	64862	GROMMET	1
13	86324	PIN-Cotter	1
14	68548	PIN-Trigger	1
15	973052	ISOLATOR-Vibration	6
16	PS97262	SLEEVE-Flanged	6
17	PA97306A	COVER, Switch	1
18	A57650A	SWITCH-Toggle	1
19	72084A1	NUT-Hex	1
20	12793A	PLATE-Indicating	1
21	93842	TRIGGER-Throttle	1
22	69889	BOOT-Throttle Rod	1
23	97294A	ROD-Throttle	1
24	68548	PIN-Trigger	1
25	95671	PIN-Throttle Lock	1
26	95020	SPRING-Compression	1
27	95989	BUSHING-Flanged	1
28	58409	RING-Retaining	1
29	A03131	FUEL CAP	1
30	A97700	USE UP06516	1
31	592531A	FILTER ELEMENT	1

MP88 Multi Purpose Saw UT-05051-B 05051-B-UT MP88 Multi Purpose Saw UT-05051-B MP88 Multi Purpose Saw
- Engine Internal




Ref #	Part #	Description	Qty
1	82246	SCREW-Mach. Hex Hd. (10-24 x 1")	4
2	973381A	BAFFLE-Cylinder	1
3	972632	BOOT-Intake	1
4	02822	ADAPTER-Intake	1
5	04635	GASKET-Intake	1
6	12021	WASHER-Conical (#10)	4
7	82246	SCREW-Cap Socket (10-24 x 1")	4
8	A02830A	CYLINDER & PISTON (Matched)	1
9	PS97316	GASKET-CYLINDER	1
10	A028241B	PISTON & PIN ASSY.	1
11	02825	PISTON RING	2
12	A03737	CRANKSHAFT & ROD	1
13	93519	BEARING-Needle	1
14	A08391	CRANKCASE ASSY.	1
15	94621A	BEARING-Ball	2
16	69833	FITTING-Tube	1
17	81208	NUT-Lock Hex (10-24)	2
18	12689A	NUT-Retainer	2
19	58308B	SEAL-Shaft	1
20	PS31062	PIN-Dowel	1
21	A02121	COVER-CYLINDER	1
22	93397A	SCREW-CYLINDER COVER	3
23	88057	SCREW-Hex Sems (10-24 x 2")	5
24	75078	KEY-Woodruff	1
NOTE1	A03611A	FOAM KIT	

MP88 Multi Purpose Saw UT-05051-B 05051-B-UT MP88 Multi Purpose Saw UT-05051-B MP88 Multi Purpose Saw -
Muffler - Handlebar



Ref #	Part #	Description	Qty
1	A04430	MUFFLER ASSY.	1
2	80983	SCREW-Mach. Hex (8-32 x 1/2")	3
3	A49545	SHIELD-Muffler	1
4	49525	CAP-Muffler	1
5	49548	SUPPORT-Spark Arrestor	1
6	98827	SCREEN-Spark Arrestor	1
7	825551	SCREW-Truss Hd. (10-24 X 3/4")	2
8	97682B	GASKET-Muffler	1
9	82592	SCREW-Cap Hex Hd. (1/4-20 X 3 1/4")	2
10	04423	SHIELD-Muffler Cover	1
11	04431A	PLATE-Retaining	1
12	A495951	HANDLE BAR	1
13	81208	NUT-Hex Lock (10-24)	2
14	825551	SCREW-Truss Hd. (10-24 X 3/4")	1
15	96212	NUT-Locking (1/4-28")	2
16	496222	BRACKET-Handle Bar	1
17	82532	SCREW-Mach. Oval Hd. (1/4-20 X 1/2")	2
18	96620	SCREW-Truss Torx (T25)	2
19	A03633	WEAR PAD KIT	1


MP88 Multi Purpose Saw UT-05051-B 05051-B-UT MP88 Multi Purpose Saw UT-05051-B MP88 Multi Purpose Saw -
Starter - Ignition



Rendered by LeadVenture, Inc.

Ref #	Part #	Description	Qty
1	A02292A	STARTER COMPLETE	1
2	A69962B	GRIP-w/Insert	1
3	A98067A	SPRING & RETAINER	1
4	84025	WASHER-Flat (#8)	3
5	82528	SCREW-Thread Form. (6 x 3/8")	2
6	A97990C	PULLEY & ROPE	1
7	A00518	ROPE	1
8	02505	SPRING-Grip	1
9	82409	SCREW-Plastite (10-14 x 5/8")	1
10	58763	WASHER-Retaining	1
11	97992A	BUSHING-Starter Post	1
12	A01827	MODULE ASSY.	1
13	A33055	TERMINAL HIGH TENS(P TBO	1
14	82562	SCREW-Hex Hd. (10-24 x 7/8")	2
15	A985831D	LEAD-Ground w/ Grommet	1
16	95479A	WASHER-Flat	1
17	81255	NUT-Lock Hex (3/8-24)	1
18	80582	SCREW-Mach. (8-32 x 5/8")	2
19	02133	SCROLL-Air Guide	1
20	A02085B	ROTOR	1
21	A03610	STARTER PAWL KIT	1
22	75078	KEY-Woodruff	1
23	98217S	SPARK PLUG (RCJ6Y)	1
24	84003	WASHER-Flat (#10)	4
25	82562	SCREW-Pan Hd. (10-24 X 5/8")	4
26	478695	COVER - Drivecase	1
27	810892	NUT-(3/8-16 x 5/16")	2
NOTE1	A03611A	FOAM KIT	

MP88 Multi Purpose Saw UT-05051-B 05051-B-UT MP88 Multi Purpose Saw UT-05051-B MP88 Multi Purpose Saw - Wheel Arm



Rendered by LeadVenture, Inc.

Ref #	Part #	Description	Qty
1	94143	Screw-Slotted	3
2	84026	Washer-Flat (1/4")	3
3	81162	Nut-Hex (5/16-18)	1
4	GP113589	Knob-Handle	1
5	43966C	Cover-Arm	1
6	81245	Nut-Hex Lock (1/2-13)	1
7	46462	"O" Ring	3
8	A03233	Pulley-Driven	1
9	46068	Belt-"V" Drive	1
10	80087	Screw-Hex Hd. (5/16-18 x 1 1/2")	1
11	A49194	USE UP03371	1
12	A49558	NLA(NO LONGER AVAILABLE)	1
13	47387	Shim	1
14	47388	Spring-Wave	1
15	49553A	Tubing-Rubber	1
16	49818	Spacer-Guard Adjusting	1
17	PS31746	Ring-Retaining	1
18	63107	Ball Bearing	2
19	47207	Retaining Ring	1
20	019051	Wheel Shaft	1
21	A01872B	Wheel Guard	1
	A01873B	Wheel Guard	1
22	48922A	Caution Label	1
23	46000	Washer-Mounting	1
	460001	Washer-mounting	1
24	82519A	Bolt-Step (5/16-18 X 1")	1
25	46065	Ring-Retaining	1
26	019091A	Flange-Wheel	1
27		Wheel-Resinoid (12" only)	1
		Wheel-Resinoid (14" only)	1
28	A03412	Bolt & Washer	1
29	49815	Bolt-Sq. Neck, Rnd. Hd.	1
30	81162	Nut-Hex (5/16-18)	1
31	84027	Washer-Flat	1
32	49553A	Tubing-Rubber	1

Ref #	Part #	Description	Qty
33	028391	Arm-Adjusting	1
	498171	Arm-Adjusting	1
34	46067	Spacer-Bearing	1
35	01902	Spacer (1" Dia.)	1
	01903	Spacer (22")	1
	01907	Spacer (20")	1

No
Diagram
Available



LEADVENTURE

Parts List
Only

Ref #	Part #	Description	Qty
	64596C	Masonry and Concrete 12 Inch Abrasive Wheel - Arbor Size: 1"	
	43230AS	Masonry and Concrete 12 Inch Abrasive Wheel - Arbor Size: 7/8"	
	49826	Masonry and Concrete 12 Inch Abrasive Wheel - Arbor Size: 20mm	
	49559	Masonry and Concrete 14 Inch Abrasive Wheel - Arbor Size: 1"	
	49765A	Masonry and Concrete 14 Inch Abrasive Wheel - Arbor Size: 20mm	
	64597C	Metal 12 Inch Abrasive Wheel - Arbor Size: 1"	
	43232AS	Metal 12 Inch Abrasive Wheel - Arbor Size: 7/8"	
	49824	Metal 12 Inch Abrasive Wheel - Arbor Size 20mm	
	49561	Metal 14 Inch Abrasive Wheel - Arbor Size 1"	
	49768A	Metal 14 Inch Abrasive Wheel - Arbor Size 20mm	
	68421B	Ductile and Cast Iron 12 Inch Abrasive Wheel - Arbor Size 1"	
	43231AS	Ductile and Cast Iron 12 Inch Abrasive Wheel - Arbor Size 7/8"	
	49825	Ductile and Cast Iron 12 Inch Abrasive Wheel - Arbor Size 20mm	
	49560A	Ductile and Cast Iron 14 Inch Abrasive Wheel - Arbor Size 1"	
	49767A	Ductile and Cast Iron 14 Inch Abrasive Wheel - Arbor Size 20mm	
	03707	Asphalt 12 Inch Abrasive Wheel - Arbor Size 1"	
	03696	Asphalt 14 Inch Abrasive Wheel - Arbor Size 1"	
	A49751A	Premium Segmented Rim 12 Inch Diamond Wheel - Arbor Size 1"	
	A49572A	Premium Segmented Rim 14 Inch Diamond Wheel - Arbor Size 1"	
	A49753A	Premium Continuous Rim 12 Inch Diamond Wheel - Arbor Size 1"	
	A04831A	Premium Continuous Rim 14 Inch Diamond Wheel - Arbor Size 1"	
	08831	Carbide, Junkyard Dog(TM) Saw Blade - Arbor Size 1"	

Ref #	Part #	Description	Qty
	A49429D	12" Wheel Arm w/ 1" Arbor - Replacement Arm Assembly	
	A49550C	14" Wheel Arm w/ 1" Arbor - Replacement Arm Assembly	

No
Diagram
Available

LEADVENTURE

Parts List
Only

Ref #	Part #	Description	Qty
	UT05064	Dolly kit W/Depth Gage	
	A18009A	Carry Case with Insert	
	A49649	NLA(NO LONGER AVAILABLE)	
	98827	Spark Arrestor Screen	
	A24824	Combination Wrench (5/8, 3/4, & Screwdriver)	
	03000	1/2 Wrench	
	A17106B	Puller Rotor	