


MP88 w/12" Multi Purpose Saw UT-05073-A 05073-A-UT MP88 w/12" Multi Purpose Saw UT-05073-A
MP88 w/12" Multi Purpose Saw - Carburetor - Air Cleaner



Rendered by LeadVenture, Inc.

Ref #	Part #	Description	Qty
1	82527	SCREW - Hex Cap (10-14 X 2")	2
2	496732	SHIELD - Carburetor	1
3	49671	GASKET - Carburetor Shield	1
4	PS00100	GROMMET	2
5	PA00037	CARBURETOR	1
6	972902A	ADAPTER - Carburetor	1
7	96620	SCREW - Torx Truss (10-24 X 1/2")	2
8	PS97291	GASKET - Carburetor	1
9	PS97298	GASKET - Carb Chamber	1
10	49509A	COVER - Carb Chamber	1
11	80582	SCREW - Pan Hd (8-32 X 5/8")	4
12	49511A	BOLT	1
13	49555	FILTER - Air	1
14	94150	"O" Ring	2
15	49513	FELT PREFILTER	1
16	49512	ELEMENT - Air Filter	1
17	498981	AIR FILTER ELEMENT COVER	1
18	81162	NUT Hex (5/16-18)	1
19	A49514A	FILTER COVER	1
20	06365	KNOB	1
21	46072	RETAINING RING	1
Note1	A03611A	Foam Kit	



Multi Purpose Saw - Clutch - Crankcase



Rendered by LeadVenture, Inc.

Ref #	Part #	Description	Qty
1	88041	SCREW - Hex Sems (8-32 X 3/4")	3
2	93628	CLUTCH COVER	1
3	A93632B	CLUTCH SHOE	3
4	93638A	CLUTCH SPRING	3
5	93639	CLUTCH SPIDER	1
6	93650	WASHER - Thrust	1
7	A49543	PULLEY & DRUM	1
8	46071	NEEDLE BEARING	1
9	46070	RACE - Inner	1
10	46135	WASHER - Thrust	1
11	A08391	CRANKCASE ASSY (COMPLETE)	1
12	A49537A	RETAINING - Bearing	1
13	12306	SEAL	1
14	82293	SCREW - Socket Cap (10-24 X 5/8")	3
15	00191D	GASKET	1
16	82595	WHEEL ARM BOLT (5-16-18 X 2.5")	2
	81208	NUT - Hex Lock (10-24)	4
	12689A	RETAINER - Nut	2
	58308B	SEAL - Shaft	1
Note1	A03611A	Foam Kit	


MP88 w/12" Multi Purpose Saw UT-05073-A 05073-A-UT MP88 w/12" Multi Purpose Saw UT-05073-A MP88 w/12"
Multi Purpose Saw - Engine Housing



Rendered by LeadVenture, Inc.

Ref #	Part #	Description	Qty
1	A49770A	HOUSING - Engine	1
2	93410A	TANK VENT FILTER	2
3	96841	VALVE - Duck Bill	1
4	96620	SCREW - Torx Truss (10-24 X 1/2")	2
5	972902A	ADAPTOR - Carburetor	1
6	PS97291	GASKET - Carburetor	1
7	9311237	TUBING - Rubber (Fuel Line, 9 1/2")	1
8	9315723	TUBING - Rubber (Pulse Line, 6 1/2")	1
9	93385A	TRIGGER - Lock	1
10	PS97265	SPRING - Flat	1
11	972921	ROD - Choke	1
12	64862	GROMMET	1
13	86324	PIN - Cotter	1
14	68548	PIN - Trigger	1
15	973052	ISOLATOR - Vibration	6
16	PS97262	SLEEVE - Flanged	6
17	PS97306A	COVER, Switch	1
18	A57650A	SWITCH - Toggle	1
19	72084A1	NUT - Hex	1
20	12793	PLATE - Indicating	1
21	93842	TRIGGER - Throttle	1
22	69889	BOOT - Throttle Rod	1
23	97294A	ROD - Throttle	1
24	68548	PIN - Trigger	1
25	95671	PIN - Throttle Lock	1
26	95020	SPRING - Compression	1
27	95989	BUSHING - Flanged	1
28	58409	RING - Retaining	1
29	A03131	FUEL CAP	1
30	A97700	USE UP06516	1
31	592531A	FILTER ELEMENT	1


MP88 w/12" Multi Purpose Saw UT-05073-A 05073-A-UT MP88 w/12" Multi Purpose Saw UT-05073-A MP88 w/12"
Multi Purpose Saw - Engine Internal



Rendered by LeadVenture, Inc.

Ref #	Part #	Description	Qty
1	82246	SCREW - Mach. Hex Hd. (10-24 X 1")	4
2	973381A	BAFFLE - Cylinder	1
3	972632	BOOT - Intake	1
4	02822	ADAPTER - Intake	1
5	04635	GASKET - Intake	1
6	12021	WASHER - Conical (#10)	4
7	82246	SCREW - Cap Socket (10-24 X 1")	4
8	A02830A	CYLINDER & PISTON (Matched)	1
9	PS97316	GASKET - CYLINDER	1
10	A028241B	PISTON & PIN ASSY.	1
11	02825	PISTON RING	2
12	A03737	CRANKSHAFT & ROD	1
13	93519	BEARING - Needle	1
14	A08391	CRANKCASE ASSY.	1
15	94621A	BEARING - Ball	2
16	69833	FITTING - Tube	1
17	81208	NUT - Lock Hex (10-24)	2
18	12689A	NUT - Retainer	2
19	58308B	SEAL - Shaft	1
20	PS31062	PIN - Dowel	1
21	A02121	COVER - CYLINDER	1
22	93397A	SCREW - CYLINDER COVER	3
23	88057	SCREW - Hex Sems (10-24 X 2")	5
24	75078	KEY - Woodruff	1
Note1	A03611A	Foam Kit	


MP88 w/12" Multi Purpose Saw UT-05073-A 05073-A-UT MP88 w/12" Multi Purpose Saw UT-05073-A MP88 w/12"
Multi Purpose Saw - Muffler - Handlebar



Rendered by LeadVenture, Inc.

Ref #	Part #	Description	Qty
1	A04430	MUFFLER ASSY	1
2	80983	SCREW - Mach. Hex (8-32 X 1/2")	3
3	A49545	SHIELD - Muffler	1
4	49525	CAP - Muffler	1
5	49548	SUPPORT - Spark Arrestor	1
6	98827	SCREEN - Spark Arrestor	1
7	825551	SCREW - Truss Hd. (10-24 X 3/4")	2
8	97682B	GASKET - Muffler	1
9	82592	SCREW - Cap Hex Hd (1/4-20 X 3 1/4")	2
10	04423	SHIELD - Muffler Cover	1
11	04431A	PLATE - Retaining	1
12	A495951	HANDLE BAR	1
13	81208	NUT - Hex Lock (10-24)	2
14	825551	SCREW - Truss Hd. (10-24 X 3/4")	1
15	96212	NUT - Locking (1/4-28")	2
16	496222	BRACKET - Handle Bar	1
17	82532	SCREW - Mach Oval Hd (1/4-20 X 1/2")	2
18	96620	SCREW - Truss Torx (T25)	2
19	A03633	WEAR PAD KIT	1

MP88 w/12" Multi Purpose Saw UT-05073-A 05073-A-UT MP88 w/12" Multi Purpose Saw UT-05073-A MP88 w/12" Multi Purpose Saw - Starter - Ignition



Rendered by LeadVenture, Inc.

Ref #	Part #	Description	Qty
1	A02292A	STARTER COMPLETE	1
2	A69962B	GRIP - w/Insert	1
3	A98067A	SPRING & RETAINER	1
4	84025	WASHER - Flat (#8)	3
5	82528	SCREW - Thread Form (6 X 3/8")	2
6	A97990C	PULLEY & ROPE	1
7	A00518	ROPE	1
8	02505	SPRING - Grip	1
9	82409	SCREW - Plastite (10-14 X 5/8")	1
10	58763	WASHER - Retaining	1
11	97992A	BUSHING - Starter Post	1
12	A01827	MODULE ASSY	1
13	A33055	TERMINAL HIGH TENS(P TBO	1
14	82562	SCREW - Hex Hd (10-24 X 7/8")	2
15	A985831D	LEAD - Ground w/ Grommet	1
16	95479A	WASHER - Flat	1
17	81255	NUT - Lock Hex (3/8-24)	1
18	80582	SCREW - Mach (8-32 X 5/8")	2
19	02133	SCROLL - Air Guide	1
20	A02085B	ROTOR	1
21	A03610	STARTER PAWL KIT	1
22	75078	KEY - Woodruff	1
23	98217S	SPARK PLUG (RCJ6Y)	1
24	84003	WASHER - Flat (#10)	4
25	82562	SCREW - Pan Hd (10-24 X 5/8")	4
26	478695A	COVER - Drivecase	1
27	810892	NUT - (3/8-16 x 5/16")	2
Note1	A03611A	Foam Kit	

MP88 w/12" Multi Purpose Saw - Wheel Arm



Rendered by LeadVenture, Inc.

Ref #	Part #	Description	Qty
1	94143	Screw-Slotted	3
2	84026	Washer-Flat (1/4")	3
3	81162	Nut-Hex (5/16-18)	1
4	GP113589	Knob-Handle	1
5	43966C	Cover-Arm	1
6	81245	Nut-Hex Lock (1/2-13)	1
7	46462	"O" Ring	3
8	A03233	Pulley-Driven	1
9	46068	Belt-"V" Drive	1
10	80087	Screw-Hex Hd. (5/16-18 X 1 1/2")	1
11	A49194	USE UP03371	1
12	A49558	NLA(NO LONGER AVAILABLE)	1
13	47387	Shim	1
14	47388	Spring-Wave	1
15	49553A	Tubing-Rubber	1
16	49818	Spacer-Guard Adjusting	1
17	PS31746	Ring-Retaining	1
18	63107	Ball Bearing	2
19	47207	Retaining Ring	1
20	019051	Wheel Shaft	1
21	A01872B	Wheel Guard (12" only)	1
	A01873B	Wheel Guard (14" only)	1
22	48922A	Caution Label	1
23	46000	Washer-Mounting (12" only)	1
	460001	Washer-mounting (14" only)	1
24	82519A	Bolt-Step (5/16-18 X 1")	1
25	46065	Ring-Retaining	1
26	019091A	Flange-Wheel	1
27		Wheel-Resinoid	1
28	A03412	Bolt & Washer	1
29	49815	Bolt-Sq. Neck, Rnd. Hd.	1
30	81162	Nut-Hex (5/16-18)	1
31	84027	Washer-Flat	1

Ref #	Part #	Description	Qty
32	49553A	Tubing-Rubber	1
33	028391	Arm-Adjusting (12" only)	1
	498171	Arm-Adjusting (14" only)	1
34	46067	Spacer-Bearing	1
35	01902	Spacer (1" Dia.)	1
	01903	Spacer (22")	1
	01907	Spacer (20")	1

No
Diagram
Available



LEADVENTURE

Parts List
Only

Ref #	Part #	Description	Qty
	64596C	Masonry and Concrete 12" Abrasive Wheel	
	49559A	Masonry and Concrete 14" Abrasive Wheel	
	64597C	Metal 12" Abrasive Wheel	
	49561A	Metal 14" Abrasive Wheel	
	68421B	Ductile and Cast Iron 12" Abrasive Wheel	
	03707A	Asphalt 12" Abrasive Wheel	
	03696A	Asphalt 14" Abrasive Wheel	
	A49751A	Premium Segmented Rim 12" Diamond Wheel	
	A49572A	Premium Segmented Rim 14" Diamond Wheel	
	A49753A	Premium Continuous Rim 12" Diamond Wheel	
	A04831A	Premium Continuous Rim 14" Diamond Wheel	
	A06397	Standard Segmented Rim 12" Diamond Wheel	
	A06398	Standard Segmented Rim 14" Diamond Wheel	
	08831	Carbide, Junkyard Dog Saw Blade	
	A49429D	12" Wheel Arm w/1" Arbor	
	A49550C	14" Wheel Arm w/1" Arbor	

No
Diagram
Available



LEADVENTURE

Parts List
Only

Ref #	Part #	Description	Qty
	UT05064	Dolly kit W/Depth Gage	
	A18009A	Carry Case with Insert	
	A49649	NLA(NO LONGER AVAILABLE)	
	98827	Spark Arrestor Screen	
	A24824	Combination Wrench (5/8, 3/4, & Screw driver)	
	03000	1/2 Wrench	
	A17106B	Puller Rotor	