



Model MT01R1/Z Parts List

A = Standard Equipment

O = Circuit Diagram

Item#	Part#	Description	Q'ty	Unit
001	266429-2	TAPPING SCREW 3X16	12	PC.
002	183E32-3	MOTOR HOUSING SET	1	
	C10 263039-6	RUBBER PIN 4	3	PC.
	C20 424859-5	CUSHION	2	
	D10	INC. 28		
003	852E50-9	MT01 NAME PLATE	1	
004	962151-6	RETAINING RING R-32	1	PC.
005	253368-5	WASHER 16	1	
006	210147-4	BALL BEARING 6902	1	
007	326719-6	CRANK SHAFT	1	
008	456788-4	SPACER 21	1	
009	210147-4	BALL BEARING 6902	1	
010	210144-0	SPHERE BEARING 505	1	
011	961008-8	RETAINING RING S-5	1	PC.
015	144085-7	CRANK HOUSING COMPLETE	1	
016	213987-9	O-RING 25	1	PC.
017	213021-5	O RING 5	1	PC.
018	224455-7	OUTER FLANGE 22	1	PC.
019	266783-4	HEX.SOCKET C.S.H.SCREW M6X20	1	PC.
020	456791-5	SWITCH KNOB	1	
021	424833-3	SPACER	1	
022	629220-3	DC MOTOR	1	
023	424467-2	CAP	1	PC.
024	651610-2	SWITCH	1	
025	424860-0	SWITCH COVER	1	
026	620522-0	CONTROLLER	1	
	C10 620543-2	LED CIRCUIT	1	
027	644813-5	TERMINAL	1	
028	183E32-3	MOTOR HOUSING SET	1	
	C10 263039-6	RUBBER PIN 4	3	PC.
	C20 424859-5	CUSHION	2	
	D10	INC. 2		
A01	783233-9	HEX. WRENCH 5	1	PC.
A02	196271-6	ADAPTER A SET	1	PC.
A03	313249-6	ADAPTER C	1	PC.
A04	A-95255	PLUNGE CUT SAW BLADE 32 TMA010	1	PC.
A05	143644-4	PLASTIC CASE COMPLETE	1	(MT01R1)
	C10 162302-3	LATCH	2	PC. (MT01R1)
	C20 838502-4	INNER TRAY	1	(MT01R1)
A06	456128-6	BATTERY COVER	1	(MT01R1)
A07	***DC10WD	DC10WD BATTERY CHARGER	1	(MT01R1)
	D10	COMPO-PARTS		
A08	BL1021B	BATTERY BL1021B SET	2	(MT01R1)
E01	809F95-4	CAUTION LABEL	1	