



Parts List for NPS1018 Type 1

Item Number	Part Number	Description	Qty Required
1	90507629	SWITCH BOOT	1
2	000000-00	No Longer Available	1
3	90507642	O-RING	1
4	90507619	CLAMSHELL SET	1
5	5100035-03	SPRING	2
6	5100034-00	TERMINAL BLOCK	1
7	90507633	LANYARD	1
8	000000-00	No Longer Available	1
9	90507618	HANDLE ASSEMBLY	1
10	000000-00	No Longer Available	1
11	90507641	O-RING	3
12	000000-00	No Longer Available	1
13	000000-00	No Longer Available	1
856	000000-00	No Longer Available	1
856	000000-00	No Longer Available	1
856	000000-00	No Longer Available	1
856	000000-00	No Longer Available	1
862	90507656	CARRYING BAG	1
866	HPB18	BATTERY	1
867	5102026-00	BATTERY CAP	1
871	5103069-12	CHARGER	1