



## Parts List for PC15TCS Type 1

Item Number	Part Number	Description	Qty Required
1	5140071-59	ARBOR BOLT	1
2	5140034-36	CLAMP	1
4	5140034-34	INNER FLANGE	1
5	5140034-04	SCREW	1
6	5140071-63	L GUARD LEVER	1
7	5140034-02	CIRCLIP	1
8	5140071-65	LOWER GUARD	1
9	5140033-99	BUSHING	1
10	5140034-00	TORSION SPRING	1
11	5140071-69	SCREW	3
12	5140071-70	GEAR ASSY.	1
13	5140071-71	HEX SOC HD SCR	1
14	5140071-72	STOPPER	1
15	5140071-73	GEAR CASE ASSY.	1
16	5140033-93	SPRING	1
17	5140033-92	SPINDLE LOCK	1
18	5140033-91	BUTTON	1
19	5140033-71	RUBBER RING	1
20	5140034-18	E-RING	1
21	5140071-80	FAN BAFFLE	1
22	5140071-81	ARMATURE	1
23	5140033-66	WASHER	1
24	5140033-65	SPRING	1
25	5140033-75	SCREW	2
26	5140033-74	SPRING WASHER	2
27	5140033-73	PLAIN WASHER	2
28	5140071-87	FIELD	1

## Parts List for PC15TCS Type 1

Item Number	Part Number	Description	Qty Required
30	5140071-89	FRONT HANDLE	1
31	5140071-90	SCREW	1
32	5140033-62	BRUSH	2
33	5140033-63	BRUSH HOLDER	2
34	5140033-61	BRUSH HOLDER PLATE	2
35	5140071-94	SCREW	3
37	5140071-96	BOLT	2
42	5140076-37	TUBE	2
43	5140034-10	CONNECTOR	1
44	5140076-39	ASSY WIRE	1
45	5140076-40	SLEEVE	1
46	5140076-41	ASSY WIRE	1
47	5140034-12	CORD PROTECTOR	1
48	5140034-11	SPONGE	1
49	5140033-76	SCREW	3
50	5140076-45	SWITCH	1
52	5140076-47	SCREW	7
56	5140034-39	WRENCH	1
57	5140076-52	SPRING PIN	1
61	5140076-56	CORD SET	1
62	5140034-13	CORD CLAMP	1
63	5140034-14	SCREW	2
65	5140076-60	MOTOR HOUSING	1
66	5140076-61	END COVER	1
67	5140076-62	SPACER	2
68	5140076-63	LOCK NUT	2
69	5140076-64	LEVER	2

## Parts List for PC15TCS Type 1

Item Number	Part Number	Description	Qty Required
70	5140076-65	WASHER	2
71	5140076-66	E-RING	2
72	5140076-67	SHOE ASSY.	1
73	5140076-68	SCREW	1
74	5140034-27	NUT	1
75	5140076-70	HANDLE COVER	1