




2



3




1




866

867



871



Parts List for PC1800FL Type 1

Item Number	Part Number	Description	Qty Required
1	90534275	KRYPTON BULB	1
2	90535301	FLASHLIGHT	1
3	90534120	HOLDER,BULB	1
866	90543485	18V BATTERY	1
867	90535852	CAP,BATTERY	1
871	90545445-02	CHARGER	1