



Parts List for PC1800ID Type 1

Item Number	Part Number	Description	Qty Required
2	90542892-01	SWITCH ASSEMBLY	1
4	486562-00	SCREW	1
5	486563-00	SCREW	7
6	498618-00	SPRING PIN	4
7	5100035-03	SPRING	2
8	90510640	RUBBER RING	1
9	90530646-02	TERMINAL BLOCK	1
10	90533048	BIT HOLDER	1
11	90542785-01	CLAMSHELL SET	1
12	90542786	F/R ACTUATOR	1
14	90543473	NUT	2
15	90550856	MOTOR & GEARBOX	1
20	90551011	BELT HOOK	1
21	90544763	SCREW	1
862	90544879	TOOL BAG	1
866	PC18B	BATTERY PACK	1
866	90543485	18V BATTERY	1
867	90535852	CAP,BATTERY	1
871	90550550-02	CHARGER	1
871	90545445	CHARGER	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.