





## Parts List for PC305TP Type 1

Item Number	Part Number	Description	Qty Required
1	A09512	WRENCH	1
2	N030691	COVER	1
3	1344933	SCREW	1
4	N030689	HANDLE	1
5	A07255	HANDLE	1
6	1342184	SLEEVE	1
7	000000-00	No Longer Available	7
8	330016-07	WASHER	2
9	1343856	AIR MANIFOLD	1
10	N030692	COVER	1
11	1246135	SCREW	4
12	A07257	KNOB	1
13	1343855	DUST CHUTE	1
14	A16194	WARNING LABEL	1
15	1246196	EXT RET RING	3
16	1343882	CHAIN	2
17	1343881	SPROCKET	4
18	1343916	SPACER	1
19	1343915	SCREW	4
20	1246050	CAP SCREW	2
21	1343947	OUTSIDE COVER	1
22	920040131276	BEARING	1
23	1343912	SHAFT	1
24	A07264	CUTTER HEAD	1
25	1343908	BUSHING	5
26	1343911	GEAR	1
27	1343910	GEAR	1

## Parts List for PC305TP Type 1

Item Number	Part Number	Description	Qty Required
28	1343909	GEAR	1
29	1343907	SPACER UNDERCUT	4
30	1343906	SPACER	2
31	1343946	INSIDE COVER	1
32	1343902	COVER	1
33	1343903	PINION GEAR	1
34	1086894	BEARING	2
35	1342213	KNIFE REMOVAL TOOL	1
36	1343862	CABLE CLAMP	1
37	1343864	PLATE	2
38	1342204	SPRING	4
39	5140010-48	SCREW	2
40	045687-00	STAR WASHER	4
41	A07258	CURSOR	1
42	1349863	FLAT WASHER	2
43	1246000	MACH SCREW	2
44	1343937	MOTOR PIVOT ROD	1
45	N029968	NAMEPLATE	1
46	1343858	BELT GUARD	1
47	1340637	WASHER	2
48	1246051	CAP SCREW	29
49	1343857	BRACKET	1
50	1342145	CUTTERHEAD PIN	4
51	1310105	SCREW	1
52	N030693	UPPER FRAME	1
53	PC22562	PLANER KNIVES	2
54	1342143	KNIFE LOCKING BAR	2

## Parts List for PC305TP Type 1

Item Number	Part Number	Description	Qty Required
55	1343866	KEY	1
56	899311	SCREW-TORX PLUS	12
57	1342217	TOOL HOLDER	1
58	A07260	RETAINER	1
59	A07287	BLOCK	1
60	1343871	BEARING RETAINER	1
61	A07261	RETAINER	1
62	1343872	CUTTERHEAD PULLEY	1
63	22-546	BELT 12IN PLANER	1
64	1343849	HEX NUT	1
65	1343873	MOTOR PULLEY	1
69	1343878	SPRING INFEED	2
73	1343879	INFEED ROLLER	1
76	1343874	SPRING	2
77	1343876	OUTFEED ROLLER	1
100	1343859	NUT	2
101	1343861	ELEVATING NUT R.H.	1
102	1343863	ELEVATING NUT L.H.	1
103	1343883	POST	4
104	1343892	SPINDLE LH	1
107	N030694	COVER	1
108	1243476	NUT	4
112	1343894	GUIDE	2
113	A07262	PLATEN	1
114	1343886	BOOT	2
115	1343884	SPINDLE RH	1
117	1343887	THRUST BEARING	2

## Parts List for PC305TP Type 1

Item Number	Part Number	Description	Qty Required
119	1343888	RETAINER	2
120	N030695	BASE	1
121	1343889	THRUST BEARING ASSY	2
122	1343890	GEAR	4
123	1343891	NUT	2
124	488829-00	SCREW	4
126	1343897	SCALE	1
127	N030696	COVER	1
129	1243503	RING	2
130	1343899	SHAFT	1
132	1343898	SUPPORT	2
135	903405	TABLE SUPPORT	4
136	1342198	SPRING WASHER	4
137	1342133	TABLE BUSHING	4
138	1246067	MACH SCREW	4
139	903307	INFEED/OUTFEED TABLE	2
140	1246177	SCREW	8
141	000000-00	No Longer Available	4
142	489128-00	HEX HD SCREW	4
143	1343948	GEAR BOX	1
150	1343919	MOTOR CORD	1
151	488979-00	WIRE NUT	1
152	438010040062	HEYCO BUSHING 5/8	1
153	000000-00	No Longer Available	3
154	488808-00	LOCK WASHER	8
155	N030698	HOUSING	1
156	A16930	WARNING LABEL	1

## Parts List for PC305TP Type 1

Item Number	Part Number	Description	Qty Required
157	905749	SWITCH PLATE	1
158	1343923	SCREW	4
159	N030699	SWITCH	1
160	N030700	KEY	1
161	1343924	GASKET	1
162	N030701	COVER	1
163	1343926	DEFLECTOR	1
164	1343927	SCREW	3
166	1343928	END COVER	1
167	1343923	SCREW	1
168	1343920	BONDING WIRE	1
170	1343929	WAVY WASHER	1
171	920040131045	BEARING	2
172	A00904	ARMATURE ASSY	1
173	1343931	SLEEVE	1
174	1343943	FIELD	1
175	1343932	SCREW	2
177	905883	MOTOR HOUSING	1
178	1343936	BRUSH CAP	2
179	1313113	BRUSH	2
180	1343934	BRUSH HOLDER	2
181	1246008	SET SCREW	2
182	1246195	INT RET RING	1
184	1343850	INSULATOR	1
185	N030706	MOTOR ASSEMBLY	1