



Parts List for PC75TRS Type 1

Item Number	Part Number	Description	Qty Required
1	90566153	HOUSING ASSY.	1
2	330019-03	SCREW	6
3	90563648	GEAR CASE	1
4	90563820	THRUST PLATE	1
5	616037-00	SCREW	4
6	90564577	GEAR ASSY.	1
7	622484-00	FLAT HD SCREW	2
8	385238-00	NEEDLE BEARING	1
9	90564572	RECIP. SHAFT ASSY.	1
10	90563824	SLEEVE BEARING	1
11	90563826	PLATE, BEARING	2
12	330045-45	SCREW	4
13	90564578	SHOE ASSEMBLY	1
14	797190	SCREW	2
15	90563185	HANDLE ASSY.	1
16	90561404	SWITCH	1
17	329301-00	CLAMP,CORD	1
18	330019-01	SCREW,TORX HD	2
19	330005-01	PROTECTOR,CORD	1
20	90566158	CORD SET	1
22	90562316	BRUSH BOX	2
23	90562908	BRUSH & SPRING	2
24	90561435	BRUSH HOLDER	2
25	330019-41	SCREW	1
28	330019-12	SCREW	4
30	330019-13	SCREW,M4X19	8
31	90563418	SCREW	2

Parts List for PC75TRS Type 1

Item Number	Part Number	Description	Qty Required
32	582717-00	WASHER	1
61	574853-08	BEARING	1
62	90565402	BEARING CUP	1
63	488950-00	BALL BEARING	1
64	696060-00	SNAP RING	1
65	90562523	COLLAR,DEFLECTOR	1
66	90562333	TORSION SPRING	1
67	90562334	SLEEVE	1
68	90562314	BLADE PIN	1
69	90562332	BL CLAMP COLLAR	1
70	90563707	SPIRAL PIN	1
71	90562315	BLADE CLAMP BOOT	1
72	603394-00	SPIRAL PIN	1
73	90563823	SLEEVE BEARING	1
74	90563821	FELT	1
75	574853-04	BEARING	1
120	90561359	ID LABEL	1
121	90562411	NAME PLATE	1
122	90564194	WARNING LABEL	1