





Parts List for PCB375SS Type 1

Item Number	Part Number	Description	Qty Required
1	5140078-37	COMPRESSION SPRING	1
2	000000-00	No Longer Available	1
3	5140138-96	FOOT	3
4	5140078-42	BELLOWS	1
5	5140078-43	PLUG,HOUSING	1
6	5140078-44	PVC HOSE	1
7	5140138-97	BOLT CLAMP	1
8	5140078-50	HEX WRENCH	1
9	5140078-51	FLAT WASHER	2
10	5140078-52	FLAT WASHER	3
11	5140138-98	WASHER	2
12	283716-00	WASHER,LOCK	1
13	000000-00	No Longer Available	1
14	5140078-56	WAVY WASHER	1
15	5140138-99	SPRING PIN	2
16	5140084-38	SPRING PIN	2
17	5140139-00	SPRING PIN	1
18	5140139-01	O-RING	2
19	5140078-58	HEX HEAD BOLT	1
20	5140139-02	HEX SOC.HD.BOLT	3
21	5140078-60	HEX HEAD BOLT	1
22	5140141-95	HEX SOC HD SCR	1
23	5140078-63	HEX SOC HD SCR	2
24	5140139-03	HEX SOC HD SCR	1
25	5140139-04	HEX HEAD SCREW	8
26	000000-00	No Longer Available	3
27	5140139-05	HEX SOC HD SCR	1

Parts List for PCB375SS Type 1

Item Number	Part Number	Description	Qty Required
28	5140078-66	SCREW	4
29	5140078-68	SCREW	3
30	5140078-70	SCREW	2
31	5140082-31	TRUSS HEAD SCREW	2
32	5140078-71	SCREW	4
33	5140083-55	SCREW	1
34	5140105-04	PAN HEAD SCREW	1
35	5140082-38	SELF TAPPING SCREW	2
36	5140077-72	SCREW	3
37	5140078-74	SCREW	1
38	5140139-06	PAN HEAD SCREW	10
39	5140139-07	PAN HEAD SCREW	1
40	5140082-48	HEX NUT	1
41	5140078-78	LOCK NUT	1
42	284867-00	CHUCK,NUT	2
43	5140139-08	WIRE CONNECTOR	1
44	5140077-89	CABLE TIE	2
45	5140139-09	PAN HEAD SCREW	1
46	5140139-10	PAN HEAD SCREW	2
47	5140139-11	HEX SOC HD SCR	1
48	5140139-12	TRUSS HEAD SCREW	1
49	5140139-13	SPACER	1
50	5140139-14	BRACKET STOP	1
51	5140139-15	CROWN NUT	1
52	5140139-16	SQUARE NUT	1
53	5140139-17	ROLL PIN	1
54	5140078-94	TURNTABLE	1

Parts List for PCB375SS Type 1

Item Number	Part Number	Description	Qty Required
55	5140078-95	SPRING GUARD	1
56	5140139-18	ROCKER SWITCH	1
57	000000-00	No Longer Available	2
58	5140079-02	TURN TABLE COVER	1
59	5140079-03	PLATE, COVER	1
60	5140079-04	GUIDE HOLDER	1
61	5140079-05	COVER	1
62	5140079-07	WIRE ROPE ASSY.	1
63	000000-00	No Longer Available	2
64	5140139-19	PAN HEAD SCREW	2
65	5140141-96	PAN HEAD SCREW	1
66	5140079-16	ROCKER SWITCH	1
67	5140079-23	TENSION HANDLE	1
68	5140079-24	PLUNGER HANDLE	1
69	5140079-28	FOLLOWER PLATE	1
70	5140079-30	CAUTION LABEL	1
71	5140079-32	LABEL	1
72	5140079-35	LABEL	1
73	5140139-20	BASE GROUP	1
74	5140139-21	BASE GROUP	1
75	5140139-22	BOTTOM ARM ROCKER	1
76	5140139-23	UPPER ARM ROCKER	1
77	5140139-24	SWITCH BOX COVER	1
78	5140139-25	SWITCH BOX GROUP	1
79	5140139-26	TABLE	1
80	5140139-27	BLADE BOX	1
81	5140139-28	RETAINER CLIP	1

Parts List for PCB375SS Type 1

Item Number	Part Number	Description	Qty Required
82	5140139-29	BODY ASSY.	1
83	5140139-30	MOTOR COVER	1
84	5140139-31	HOUSING,RIGHT	1
85	5140139-32	HOUSING	1
86	5140139-33	ADJUST BOLT	1
87	5140139-34	SIDE COVER	1
88	5140139-35	DUST COLLECTOR	1
89	5140139-36	SWITCH BOX COVER	1
90	5140139-37	PUSH BUTTON	1
91	5140139-38	TILT BRACKET	1
92	5140139-39	SIDE COVER	2
93	5140139-40	CLAMP HANDLE	1
94	5140139-41	SPECIAL BOLT	2
95	5140139-42	LOCKING ROD	1
96	5140139-43	GUIDE BLOCK	1
97	5140139-44	SHAFT, PIVOT	1
98	000000-00	No Longer Available	1
99	5140139-46	RETAINING CLIP	1
100	5140139-47	LINK BAR	1
101	5140139-48	ECCENTRIC	1
102	5140139-49	TRUNNION BRACKET	1
103	5140139-50	AIR DUCT ASSY.	1
104	5140139-51	MOTOR ASSY.	1
105	5140139-52	LED LIGHT	1
106	5140139-53	CONTROLLER ASSY	1
107	5140139-54	INSERT	1
108	5140139-55	LEAD WIRE ASSY	1

Parts List for PCB375SS Type 1

Item Number	Part Number	Description	Qty Required
109	5140139-56	LEADWIRE ASSY.	1
110	5140139-57	RESISTOR ASY.	1
111	5140139-58	BLADE HOLDER ASSY.	2
112	5140139-59	BEARING SEAT ASSY.	1
113	5140139-60	ROLL PIN	1
114	5140139-61	SUPPORT ROD	1
115	5140139-62	ANCHOR PLATE	1
116	5140139-63	PAN HEAD SCREW	1
117	5140139-64	LABEL	1
118	5140139-65	CAUTION LABEL	1
119	5140139-66	TILTING SCALE	1
120	5140139-67	WARNING LABEL	1
121	5140139-68	CAUTION LABEL	1
200	5140079-55	WARNING LABEL	1
201	5140139-72	UPPER SUPPORT	2
202	5140139-73	SUPPORT BRACKET	1
203	5140139-74	SUPPORT BRACKET	1
204	5140139-75	SUPPORT BRACKET	2
205	5140139-76	UPPER SUPPORT	1
206	5140139-77	BRACKET	2
207	5140139-78	BRACKET	2
208	5140139-79	UPPER SUPPORT	1
209	5140139-80	CAUTION LABEL	2
210	5140139-81	CAUTION LABEL	2
846	5140139-82	HARDWARE BAG	4