



Parts List for PCB420SA Type 1

Item Number	Part Number	Description	Qty Required
1	5140086-46	RUBBER FOOT	4
2	5140086-47	SCREW	16
3	5140086-48	BOTTOM PLATE	1
4	5140086-49	SCREW	4
5	5140086-50	LOCK WASHER	6
6	5140086-51	FLAT WASHER	6
7	5140086-52	BASE	1
8	5140086-53	CONNECTOR TUBE	1
9	5140086-54	PULLEY,LARGE	1
10	5140086-55	POLY-V BELT	1
11	5140086-56	COLLECTOR BEARING	1
12	5140086-57	SPRING WASHER	1
13	5140086-58	SCREW	14
14	5140086-59	FAN COVER	1
15	5140086-60	FAN	1
16	5140086-61	WASHER	4
17	5140086-62	SPRING WASHER	4
18	5140086-63	SCREW	2
19	5140086-64	FAN HOUSING	1
20	5140086-65	SCREW	12
21	5140086-66	FRONT COVER	1
22	5140086-67	DUST STORAGE BOX	1
24	5140086-69	EXHAUST COVER	1
25	5140086-70	DUST EXHAUST	1
26	5140086-71	HEX NUT	2
30	5140086-75	TOOTH WASHER	2
31	5140086-76	SLEEVE	1

Parts List for PCB420SA Type 1

Item Number	Part Number	Description	Qty Required
32	5140086-77	PIN	1
33	5140086-78	SCREW	2
34	5140086-79	KNOB	1
35	5140086-80	FLAT WASHER	4
36	5140086-81	RUBBER WASHER	1
37	5140086-82	ADJUSTING SPRING	1
38	5140086-83	BELT FRAME	1
39	5140086-84	TENSION SPRING	1
40	5140086-85	SLEEVE	2
41	5140086-86	SPRING WASHER	2
42	5140086-87	BEARING	2
45	5140086-90	BELT TENSION ASSY.	1
46	5140086-91	HEX SCREW	8
47	5140086-92	WASHER	3
49	5140086-94	DRIVE PULLEY	1
50	5140086-95	HEX SCREW	1
51	5140086-96	COLLECTOR SHAFT	1
52	5140086-97	SCREW	2
53	5140086-98	FLAT WASHER	5
54	5140086-99	ANGLE POINTER	1
55	5140087-00	BELT FRAME CONNECTOR	1
56	5140087-01	BUSHING,CORD	1
57	5140087-02	BELT COVER	1
58	5140087-03	PIN	1
59	5140087-04	SPRING WASHER	1
60	5140087-05	RIGHT COVER	1
61	5140087-06	LEFT COVER	1

Parts List for PCB420SA Type 1

Item Number	Part Number	Description	Qty Required
62	5140087-07	SMALL PULLEY	1
63	5140087-08	SCREW W/WASHER	1
64	5140087-09	BELT EXHAUST	1
65	5140087-10	MOUNTING SHAFT	2
66	5140087-11	HEX SCREW	3
67	5140087-12	MOUNTING PLATE	1
68	5140087-13	END CAP	1
69	5140087-14	POWER CORD	1
70	5140087-15	STRAIN RELIEF	1
71	5140087-16	WIRE BOX COVER	1
72	5140087-17	SCREW	1
73	5140087-18	RELAY	1
74	5140087-19	WIRE BOX COVER	1
75	5140087-20	END CAP - LEFT	1
76	5140087-21	KEY	1
77	5140087-22	WASHER	1
78	5140087-23	SCREW	1
79	5140087-24	DISC COVER	1
80	5140087-25	SCREW	6
81	5140087-26	ANGLE POINTER	2
83	5140087-28	HANDLE ASSEMBLY	2
84	5140087-29	DISC WORK TABLE	1
88	5140087-33	BEARING	2
89	5140087-34	ROTOR	1
90	5140087-35	SCREW	4
91	5140087-36	STATOR	1
92	5140087-37	HEX NUT	5

Parts List for PCB420SA Type 1

Item Number	Part Number	Description	Qty Required
93	5140087-38	MOTOR COVER	1
94	5140087-39	SWITCH COVER	1
95	5140087-40	SCREW	2
96	5140087-41	SWITCH	1
97	5140087-42	TUBE CONNECTOR	1
98	5140087-43	CAPACITOR SUPPORT	1
99	5140087-44	CAPACITOR	1
100	5140087-45	HEX HEAD SCREW	2
101	5140087-46	CAPACITOR SUPPORT	1
102	5140087-47	CAPACITOR	1
103	5140087-48	DISC PLATE	1
104	5140087-49	FLAT WASHER	7
105	5140087-50	HEX HEAD SCREW	1
106	5140087-51	DUST BAG	1
107	5140087-52	POSITION SHAFT	1
108	5140087-53	MITER POINTER	1
109	5140087-54	HEX NUT	3
110	5140087-55	DUST COVER	1
111	5140087-56	LABEL	1
112	5140087-57	WARNING LABEL	1
113	5140087-58	WARNING LABEL	1
114	5140087-59	SCALE LEFT	1
115	5140087-60	SCALE RIGHT	1
116	5140087-61	ROTATION LABEL	2
117	5140087-62	BELT TENSION LABEL	1
118	5140087-63	HEX WRENCH	1
119	5140087-64	SCALE LABEL	1

Parts List for PCB420SA Type 1

Item Number	Part Number	Description	Qty Required
120	5140087-65	SPRING WASHER	1
121	5140087-66	SPRING WASHER	5
122	5140087-67	TENSION HANDLE ASSY.	1
123	5140087-68	ANGLE LABEL	1
124	5140087-69	POSITIONING PLATE	1
125	5140087-70	FLAT WASHER	2
126	5140087-71	TOOTH WASHER	1
127	5140087-72	BEARING BUSHING	1
129	5140087-74	SPRING WASHER	8
130	5140087-75	KNOB	1
131	5140087-76	HEX SCREW	1
133	5140087-78	SPRING WASHER	6
134	5140087-79	SCREW	8
135	5140087-80	FLAT WASHER	5
136	5140087-81	LOCK WASHER	1
137	5140087-82	FLAT WASHER	1
138	5140087-83	BAG CLAMP	1
139	5140087-84	IDLER PULLEY ASSY	1
140	5140087-85	TABLE ASSY.	1
141	5140087-86	SUPPORT ASSY.	1
142	5140087-87	SUPPORT ASSY.	1
143	5140087-88	MITER GAGE ASSY.	1