



Parts List for PCC740LA Type 1

Item Number	Part Number	Description	Qty Required
1	90626762	HOUSING SET	1
3	N496497	RATING LABEL	1
4	90639562	SWITCH ASSEMBLY	1
5	N457442	MOTOR IMPACT ASSY	1
6	5106167-00	SCREW	7
7	330019-07	SCREW,THD.FORM	4
8	486578-00	SCREW	2
9	90569693-03	F/R ACTUATOR	1
10	5100035-03	SPRING	2
11	90641005	LOCK WASHER	4
866	PCC685L	BATTERY	1
871	90634912	CHARGER	1