



Parts List for PCE141 Type 1

Item Number	Part Number	Description	Qty Required
3	90538663	BRUSH RING	1
4	90545899	BRUSH	2
5	90568025	SPACER	2
9	90564365-01	SHIFTER ASSEMBLY	1
20	90606279	SWITCH	1
22	90539961	CORD PROTECTOR	1
23	329301-00	CLAMP,CORD	1
24	90578994-27	CORDSET	1
25	90571892	LEAD	1
26	90571893	LEAD	1
30	330033-23	CHUCK	1
32	90552945	SCREW	1
33	330019-32	SCREW	4
34	330019-01	SCREW PLASTITE	3
35	330019-03	SCREW,PLASTITE	7
41	90577908	DEPTH STOP	1
42	90570065	SIDE HANDLE	1
44	330034-07	CHUCK KEY	1
45	90538196	CHUCK KEY HOLDER	1
800	286436-00	GREASE, 500GRAMS	1