









Parts List for PCI2200-B2 Type 1

Item Number	Part Number	Description	Qty Required
1	285820-28	FUEL TANK	1
2	285820-00	FUEL CAP	1
4	285820-01	GASKET	1
5	285820-02	FUEL FILTER	1
6	285820-03	FUEL VALVE	1
7	285820-04	GAUGE	1
8	285820-05	FLAT WASHER	4
9	285820-06	SPACER	4
10	285820-07	RUBBER CUSHION	4
11	285820-08	SCREW	2
13	285815-09	CLIP	2
14	285818-08	HOSE	1
16	5140101-00	CASE	1
17	5140066-69	SCREW	1
18	5140101-01	CONTROL PANEL	1
19	5140101-02	TRANSITION SWITCH	1
21	5140066-85	FRAME	1
22	5140066-39	CUSHION	1
24	285815-75	NUT	8
25	5140066-87	ISOLATOR	2
26	5140066-86	ISOLATOR	2
29	5140066-43	SHOCK ABSORBER	1
30	5140066-89	GUARD PLATE	1
34	5140066-88	STAY	1
40	5140100-98	GROUND STRAP	1
41	5140100-99	BRACKET	1
42	285819-20	BOLT	4

Parts List for PCI2200-B2 Type 1

Item Number	Part Number	Description	Qty Required
43	5140100-96	GENERATOR ASSY	1
44	5140066-93	BOLT	4
45	5140066-67	FLAT WASHER	1
46	5140066-96	BOLT	1
47	5140066-92	REAR HOUSING	1
50	5140066-91	BRUSH ASSEMBLY	1
51	5140067-19	BOLT	2
53	5140100-97	VOLTAGE REGULATOR	1
54	5140066-95	END COVER	1
102	N009734	LABEL	1
105	N010764	WARNING LABEL	1
106	N028849	CAUTION LABEL	1
107	N028848	WARNING LABEL	1
108	N009562	INSTRUCTION LABEL	1
109	N009083	WARNING LABEL	2
110	N024486	LABEL	1
400	285814-00	BOLT	4
401	285814-02	DRAIN PLUG	2
402	285814-03	BOLT	1
404	285819-03	BOLT	2
406	285814-07	WASHER	1
407	285820-25	FLAT WASHER	2
408	285814-11	SPECIAL NUT	1
409	285814-15	OIL SEAL	2
410	285814-17	DOWEL PIN	2
411	285814-19	DOWEL PIN	2
412	285814-21	BALL BEARING	1

Parts List for PCI2200-B2 Type 1

Item Number	Part Number	Description	Qty Required
413	285800-98	SPARK PLUG	1
414	285814-24	GASKET	1
415	285820-19	GASKET	1
416	285820-17	CYLINDER HEAD	1
417	285820-18	COVER	1
418	285815-88	BOLT	6
419	285820-22	CRANKCASE	1
420	285820-23	SWITCH ASSEMBLY	1
421	285819-17	OIL ALERT UNIT	1
422	285820-27	COVER	1
423	285814-44	GASKET	1
424	285820-29	CAP ASSY.	1
427	285820-33	CRANKSHAFT	1
428	285820-34	KEY	1
429	285820-32	PISTON PIN	1
430	285814-60	CLIP	2
431	285814-62	RING SET	1
432	285820-31	CONNECTING ROD	1
433	285820-37	LIFTER	2
434	285820-63	PUSH ROD	2
436	285820-38	VALVE KIT	1
437	285814-79	VALVE SPRING	2
439	285820-41	SEAL	1
440	285820-39	ROTATOR VALVE	2
441	285820-42	CAMSHAFT	1
442	285820-36	PLATE	1
443	285820-35	ARM ASSEMBLY	2

Parts List for PCI2200-B2 Type 1

Item Number	Part Number	Description	Qty Required
444	285820-47	SHROUD	1
445	285820-49	GASKET	1
446	285815-06	GASKET	1
448	285816-30	CLIP	1
450	285820-51	FAN	1
451	285820-52	STARTER PULLEY	1
452	285820-50	FLYWHEEL	1
455	285820-53	IGNITION COIL	1
457	285815-29	GASKET	1
458	285815-32	GASKET	1
460	285820-30	PISTON	1
461	285820-56	SPRING	1
462	285820-54	SPRING	1
463	285820-55	ARM	1
464	285820-24	SHAFT	1
465	285815-49	LOCK PIN	1
466	285820-26	GOVERNOR ASSY.	1
470	285820-43	STARTER ASSY.	1
471	285817-34	INSULATOR	1
472	285820-48	CARBURETOR	1
473	285820-60	AIR FILTER	1
474	285820-58	CONTROL ASSY	1
477	285815-74	NUT	7
479	285815-84	BOLT	3
480	285815-85	BOLT	6
482	285815-84	BOLT	2
484	285815-90	BOLT	6

Parts List for PCI2200-B2 Type 1

Item Number	Part Number	Description	Qty Required
486	285815-89	BOLT	1
489	285820-21	BOLT	2
491	285820-45	FAN COVER	1
495	285820-57	ROD	1
506	285820-40	VALVE RETAINER	2
509	285815-92	BOLT	6
510	285819-69	GROMMET	1
530	285820-44	ROPE	1
531	285816-83	CAP ASSY.	1
533	285820-59	AIR FILTER	1
547	285817-12	SCREW	1
554	285816-06	TUBE	1
559	285820-71	HANDLE	1
560	285820-46	COVER PLATE	1
620	285819-90	BOLT	3
621	285815-86	BOLT	5
622	285820-62	BRACKET	1
625	285820-20	PROTECTOR	1
626	285820-61	MUFFLER	1