











## Parts List for PCI2800-B2 Type 1

| Item Number | Part Number | Description    | Qty Required |
|-------------|-------------|----------------|--------------|
| 1           | 285819-99   | FUEL TANK      | 1            |
| 2           | 285820-00   | FUEL CAP       | 1            |
| 4           | 285820-01   | GASKET         | 1            |
| 5           | 285820-02   | FUEL FILTER    | 1            |
| 6           | 285820-03   | FUEL VALVE     | 1            |
| 7           | 285820-04   | GAUGE          | 1            |
| 8           | 285820-05   | FLAT WASHER    | 4            |
| 9           | 285820-06   | SPACER         | 4            |
| 10          | 285820-07   | RUBBER CUSHION | 4            |
| 11          | 285820-08   | SCREW          | 2            |
| 13          | 285815-09   | CLIP           | 2            |
| 14          | 285818-08   | HOSE           | 1            |
| 15          | 285820-09   | SLEEVE         | 1            |
| 16          | 5140066-68  | SEAT           | 1            |
| 17          | 5140066-69  | SCREW          | 4            |
| 18          | 5140066-72  | CONTROL PANEL  | 1            |
| 21          | 5140066-73  | FRAME          | 1            |
| 22          | 5140066-39  | CUSHION        | 2            |
| 24          | 285815-75   | NUT            | 4            |
| 25          | 5140066-40  | ISOLATOR       | 2            |
| 26          | 5140066-41  | ISOLATOR       | 2            |
| 27          | 5140066-42  | FLANGE NUT     | 4            |
| 29          | 5140066-43  | SHOCK ABSORBER | 4            |
| 34          | 5140066-74  | STAY           | 1            |
| 35          | 285817-57   | BOLT           | 4            |
| 41          | 5140066-49  | GUARD PLATE    | 1            |
| 43          | 5140070-53  | GENERATOR ASSY | 1            |

## Parts List for PCI2800-B2 Type 1

| Item Number | Part Number | Description       | Qty Required |
|-------------|-------------|-------------------|--------------|
| 44          | 5140066-76  | BOLT              | 2            |
| 45          | 5140066-52  | FLAT WASHER       | 1            |
| 46          | 5140066-77  | BOLT              | 1            |
| 47          | 5140066-54  | REAR HOUSING      | 1            |
| 49          | 5140066-56  | WIRE TIE          | 2            |
| 50          | 5140066-57  | BRUSH ASSEMBLY    | 1            |
| 51          | 285815-83   | BOLT              | 3            |
| 52          | 5140066-78  | BOLT              | 4            |
| 53          | 5140066-59  | VOLTAGE REGULATOR | 1            |
| 54          | 5140066-60  | END COVER         | 1            |
| 55          | 5140070-58  | SUPPORT           | 1            |
| 64          | 5140067-15  | NUT               | 2            |
| 65          | 5140067-16  | WASHER            | 2            |
| 101         | N029664     | NAMEPLATE         | 1            |
| 102         | N009037     | LABEL             | 1            |
| 105         | N010764     | WARNING LABEL     | 1            |
| 106         | N028849     | CAUTION LABEL     | 1            |
| 107         | N028848     | WARNING LABEL     | 1            |
| 108         | N009562     | INSTRUCTION LABEL | 1            |
| 109         | N009083     | WARNING LABEL     | 2            |
| 110         | N024485     | LABEL             | 1            |
| 400         | 285814-01   | BOLT              | 4            |
| 401         | 285815-94   | DRAIN PLUG        | 2            |
| 402         | 285814-03   | BOLT              | 1            |
| 404         | 285819-03   | BOLT              | 2            |
| 406         | 285814-08   | WASHER            | 1            |
| 407         | 285814-10   | WASHER            | 2            |

## Parts List for PCI2800-B2 Type 1

| Item Number | Part Number | Description    | Qty Required |
|-------------|-------------|----------------|--------------|
| 408         | 285814-12   | SPECIAL NUT    | 1            |
| 409         | 285814-13   | OIL SEAL       | 2            |
| 410         | 285814-16   | DOWEL PIN      | 2            |
| 413         | 285800-98   | SPARK PLUG     | 1            |
| 414         | 285819-05   | SEAL RING      | 1            |
| 415         | 285818-97   | GASKET         | 1            |
| 416         | 285820-15   | CYLINDER HEAD  | 1            |
| 417         | 285819-00   | COVER          | 1            |
| 418         | 285818-99   | BOLT           | 1            |
| 419         | 285819-11   | CRANKCASE      | 1            |
| 420         | 285819-13   | SWITCH         | 1            |
| 421         | 285819-17   | OIL ALERT UNIT | 1            |
| 427         | 285819-38   | CRANKSHAFT     | 1            |
| 428         | 285819-32   | KEY            | 1            |
| 429         | 285819-46   | PISTON PIN     | 1            |
| 430         | 285814-60   | CLIP           | 2            |
| 431         | 285819-35   | RING SET       | 1            |
| 432         | 285819-08   | CONNECTING ROD | 1            |
| 433         | 285819-48   | LIFTER         | 2            |
| 434         | 285819-43   | PUSH ROD       | 2            |
| 436         | 285819-52   | VALVE KIT      | 1            |
| 437         | 285819-55   | VALVE SPRING   | 2            |
| 439         | 285819-62   | SEAL           | 1            |
| 440         | 285819-51   | ROTATOR VALVE  | 2            |
| 441         | 285819-58   | CAMSHAFT       | 1            |
| 442         | 285819-45   | PLATE          | 1            |
| 443         | 285819-44   | ARM ASSEMBLY   | 2            |



## Parts List for PCI2800-B2 Type 1

| Item Number | Part Number | Description    | Qty Required |
|-------------|-------------|----------------|--------------|
| 444         | 285819-06   | SHROUD         | 1            |
| 445         | 285815-03   | GASKET         | 1            |
| 446         | 285815-07   | GASKET         | 1            |
| 448         | 285815-10   | CLIP           | 2            |
| 449         | 285820-12   | STAY ASSY      | 1            |
| 450         | 285819-21   | FAN            | 1            |
| 451         | 285819-18   | STARTER PULLEY | 1            |
| 452         | 285819-77   | FLYWHEEL       | 1            |
| 453         | 285815-23   | GROMMET        | 1            |
| 455         | 285819-23   | IGNITION COIL  | 1            |
| 457         | 285815-30   | GASKET         | 1            |
| 460         | 285819-49   | PISTON         | 1            |
| 461         | 285819-86   | SPRING         | 1            |
| 462         | 285819-01   | SPRING         | 1            |
| 463         | 285819-09   | ARM            | 1            |
| 464         | 285819-30   | SHAFT          | 1            |
| 465         | 285815-49   | LOCK PIN       | 1            |
| 470         | 285819-60   | STARTER ASSY.  | 1            |
| 471         | 285819-72   | INSULATOR      | 1            |
| 472         | 285819-36   | CARBURETOR     | 1            |
| 473         | 285820-14   | FILTER ASSY.   | 1            |
| 474         | 285819-63   | CONTROL ASSY   | 1            |
| 477         | 285815-74   | NUT            | 13           |
| 482         | 285815-86   | BOLT           | 22           |
| 484         | 285815-90   | BOLT           | 6            |
| 488         | 285819-66   | FLAT WASHER    | 3            |
| 489         | 285820-16   | BOLT           | 2            |

## Parts List for PCI2800-B2 Type 1

| Item Number | Part Number | Description    | Qty Required |
|-------------|-------------|----------------|--------------|
| 491         | 285820-64   | FAN COVER      | 1            |
| 492         | 285816-07   | BUSHING        | 1            |
| 495         | 285819-67   | ROD            | 1            |
| 503         | 285815-84   | BOLT           | 3            |
| 505         | 285819-57   | SEAT           | 2            |
| 506         | 285819-53   | RETAINER       | 2            |
| 510         | 285819-69   | GROMMET        | 1            |
| 530         | 285816-82   | ROPE           | 1            |
| 531         | 285816-83   | CAP ASSY.      | 1            |
| 532         | 285819-83   | AIR FILTER     | 1            |
| 547         | 285816-97   | SCREW          | 1            |
| 549         | 285817-03   | NUT            | 2            |
| 552         | 1349856     | PAN HEAD SCREW | 1            |
| 553         | 285817-19   | SPRING         | 1            |
| 554         | 285819-78   | TUBE           | 1            |
| 559         | 285820-71   | HANDLE         | 1            |
| 601         | 285819-40   | COVER          | 1            |
| 602         | 285819-20   | BOLT           | 13           |
| 603         | 285819-79   | CAP ASSY.      | 1            |
| 605         | 285819-22   | O-RING         | 1            |
| 606         | 285819-42   | GOVERNOR ASSY. | 1            |
| 612         | 285819-34   | COVER ASSEMBLY | 1            |
| 613         | 285814-45   | GASKET         | 1            |
| 614         | 285814-18   | DOWEL PIN      | 2            |
| 616         | 285815-93   | BOLT           | 7            |
| 617         | 285816-28   | BALL BEARING   | 2            |
| 620         | 285819-90   | BOLT           | 4            |

## Parts List for PCI2800-B2 Type 1

| Item Number | Part Number | Description  | Qty Required |
|-------------|-------------|--------------|--------------|
| 622         | 285819-91   | STAY         | 1            |
| 623         | 285819-92   | SEAL         | 1            |
| 624         | 285819-93   | PROTECTOR    | 1            |
| 625         | 285819-28   | PROTECTOR    | 1            |
| 626         | 285819-26   | MUFFLER      | 1            |
| 627         | 285819-96   | PROTECTOR    | 1            |
| 628         | 285819-97   | GASKET       | 1            |
| 629         | 285819-25   | EXHAUST PIPE | 1            |
| 630         | 285816-55   | BOLT         | 2            |
| 631         | 285815-73   | NUT          | 2            |
| 632         | 285816-46   | GASKET       | 1            |