



Parts List for PF600-AR Type 1

Item Number	Part Number	Description	Qty Required
1	5140002-05	RUBBER CUP	1
2	5140002-06	BEARING	1
3	5140002-07	ARMATURE	1
4	5140002-08	RETAINING RING	1
5	5140002-09	CAP	1
6	5140002-10	BEARING	1
7	5140002-11	LOCK PIN	1
8	5140002-12	SPRING	1
9	5140002-13	RETAINING RING	1
10	5140002-14	SCREW	4
11	5140002-15	GEAR CASE	1
12	5140002-16	BEARING	1
13	5140002-17	RETAINING RING	1
14	5140002-18	SPRING RING	1
15	5140002-19	GEAR	1
16	5140002-20	CAP	1
17	5140002-21	BEARING	1
18	5140002-22	GEAR CASE COVER	1
19	5140002-23	SPRING WASHER	1
20	5140002-24	SCREW	4
21	5140002-25	GUARD	1
22	5140002-26	SCREW	1
23	5140002-27	NUT	1
24	5140002-28	SCREW	3
25	5140002-29	CORD PROTECTOR	1
26	5140002-30	SCREW	1
27	5140002-31	CORD & PLUG	1

Parts List for PF600-AR Type 1

Item Number	Part Number	Description	Qty Required
28	5140002-33	END CAP	1
29	5140002-34	SCREW	2
30	5140002-35	BRUSH	2
31	5140002-37	BRUSH HOLDER	2
32	5140002-38	FIELD CASE	1
33	5140002-39	ROLLER	1
34	5140002-40	SCREW	2
35	5140002-41	FIELD	1
36	5140002-43	HANDLE	1
37	5140002-44	FAN BAFFLE	1
38	5140002-45	PINION	1
39	5140002-46	SPRING WASHER	1
40	5140002-47	NUT	1
41	5140002-48	CORD CLAMP	1
42	5140002-49	SCREW	2
43	5140002-50	KEY	1
44	5140002-51	SPINDLE	1
45	5140002-52	FLANGE	1
46	5140002-53	CLAMP NUT	1
47	5140002-54	SWITCH	1
48	5140002-55	CAPACITOR	1
49	5140002-56	SPRING	1
50	5140002-57	ACTUATOR	1
51	5140002-58	KNOB	1
52	5140002-59	SCREW	2