



Parts List for PS1800AK Type 6

| Item Number | Part Number | Description | Qty Required |
|-------------|-------------|-----------------|--------------|
| 1 | 149518-01 | SCREW | 1 |
| 2 | 5147554-00 | KEYLESS CHUCK | 1 |
| 3 | 5102586-04 | VSR SWITCH | 1 |
| 4 | 607918-41 | SCREWDRIVER BIT | 1 |
| 5 | 5148206-00 | MOTOR & GEARBOX | 1 |
| 6 | 311978-01 | F/R ACTUATOR | 1 |
| 7 | 148354-03 | BIT CLIP | 1 |
| 866 | HPB18 | BATTERY | 1 |
| 867 | 5102026-00 | BATTERY CAP | 1 |
| 871 | 90500932 | CHARGER | 1 |
| 871 | 5103069-12 | CHARGER | 1 |