



## Parts List for PS1801RC Type 1

Item Number	Part Number	Description	Qty Required
1	000000-00	No Longer Available	1
2	90507163	RADIO CHARGER	1
3	5104532-00	ANTENNA	1
4	5104533-00	DRAWER	2