



## Parts List for PT381 Type 0

Item Number	Part Number	Description	Qty Required
1	5140067-23	MOTOR HOUSING	1
2	5140067-24	BUSHING	1
4	5140067-25	OIL SEAL	1
5	5140067-26	THROTTLE LEVER	1
9	5140067-27	BACKHEAD	1
10	5140067-28	INLET	1
11	5140067-29	O-RING	1
12	5140067-30	O-RING	1
13	5140067-31	STEEL BALL	1
14	5140067-32	SPRING	1
15	5140067-33	AIR REGULATOR	1
16	5140067-34	O-RING	1
17	5140067-35	RETAINER PLATE	1
18	5140067-36	O-RING	1
19	5140067-37	SCREW	2
20	5140067-38	WASHER	1
21	5140067-39	RETAINER	1
22	5140067-40	SPRING	2
23	5140067-41	THROTTLE VALVE	2
24	5140067-42	THROTTLE VALVE PLG.	2
25	5140067-43	SPRING	2
26	5140067-44	POWER REGULATOR	2
27	5140067-45	GASKET	1
28	5140067-46	BALL BEARING	1
29	5140067-47	REAR PLATE	1
30	5140067-48	ROTOR	1
32	5140067-49	ROTOR BLADE	6

## Parts List for PT381 Type 0

Item Number	Part Number	Description	Qty Required
33	5140067-50	CYLINDER	1
34	5140067-51	DOWEL PIN	1
35	5140067-52	FRONT PLATE	1
36	5140067-53	OIL SEAL	1
37	5140067-54	BALL BEARING	1
38	5140067-55	O-RING	1
39	5140067-56	RETAINER	1
40	5140067-57	FRAME	1
41	5140067-58	CAM	1
42	5140067-59	HAMMER	1
43	5140067-60	PIN	1
44	5140067-61	ANVIL	1
45	5140067-62	O-RING	1
46	5140067-63	RETAINER	1
48	5140067-64	WASHER	4
49	5140067-65	SCREW	4
876	5140067-66	TUNE-UP KIT	1