



## Parts List for PI100LA-B2C Type 1

| Item Number | Part Number | Description         | Qty Required |
|-------------|-------------|---------------------|--------------|
| 1           | 5140143-91  | END CAP             | 2            |
| 2           | 5140143-92  | EARTH TAP           | 1            |
| 3           | 5140143-93  | COPPER BUSHING      | 1            |
| 4           | 5140143-94  | PLUG BARREL         | 1            |
| 5           | 5140143-95  | PLUG TOP HOUSING    | 1            |
| 6           | 5140143-96  | PLUG BOTTOM HOUSING | 1            |
| 7           | 5140143-97  | GEAR                | 2            |
| 8           | 5140143-98  | BACK HOUSING        | 1            |
| 9           | 5140143-99  | TRIM HOUSING        | 1            |
| 10          | 5140144-00  | FRONT HOUSING       | 1            |
| 11          | 5140144-01  | MAIN HOUSING        | 1            |
| 12          | 5140144-02  | FUSE                | 1            |
| 13          | 5140144-03  | FAN                 | 1            |
| 14          | 5140144-04  | COPPER HEAD         | 1            |
| 15          | 5140144-05  | CLIPS               | 1            |
| 16          | 5140144-06  | SPRING              | 1            |
| 17          | 5140144-07  | PCB ASSEMBLY        | 1            |
| 18          | 5140144-08  | TRANSFORMER         | 1            |
| 19          | 5140144-09  | MOSFET1             | 2            |
| 20          | 5140144-10  | MOSFET2             | 4            |
| 21          | 5140144-11  | PCB ASSEMBLY        | 1            |
| 22          | 5140144-12  | USB ASSY.           | 1            |
| 23          | 5140144-13  | USB ASSY.           | 1            |
| 24          | 5140144-14  | USB ASSY.           | 1            |