



FIGURE A



PARTS LIST (FIGURE A)

KEY NO.	PART NUMBER	DESCRIPTION	QTY	KEY NO.	PART NUMBER	DESCRIPTION	QTY
1	660563002	Screw (M4 x 20 mm)	4	17	660697002	Bolt (M6 x 20 mm).....	1
2	308869002	Control Handle Assembly	1	18	660634001	Screw (8-16 x 5/16 in. Torx T.F.)	1
3	518695001	Trigger Lock	1	19	518696001	Throttle Trigger	1
4	638431001	Strap Hanger.....	1	20	690694002	Spring.....	1
5	760700002	Switch (Momentary Contact)	1	21	308046001	“J” Handle and Grip	1
6	570234002	Rear Handle	1	22	678013001	Washer	1
7	940654088	Combustion Warning Label.....	1	23	308487001	Shoulder Harness.....	1
8	940705011	Logo Label	1	24	518949001	Wing Nut (1/4-20).....	1
9	870174001	Spark Plug (Champion RCJ6Y).....	1	25	638565001	Bottom “J” Handle Clamp.....	1
10	940991031	Model Label (BC26).....	1	26	638564001	Top “J” Handle Clamp.....	1
11	940686059	Starting Label.....	1	27	660643001	Bolt (1/4-20 x 1-1/2 in. Hex Hd.).....	1
12	518777004	Air Box Cover	1	28	940657034	Warning Decal	1
13	310817001	Fuel Cap Assembly (1.5 in. Diameter)	1	29	308470013	Upper Boom Assembly	1
14	308842004	Throttle and Lead Assembly	1	Not Shown:			
15	678029002	Hex Nut (M6)	1	987000992	Operator’s Manual (960736006).....	1	
16	690140011	Compression Spring	1	5-24-10			
				(REV:02)			


FIGURE B



PARTS LIST (FIGURE B)

KEY NO.	PART NUMBER	DESCRIPTION	QTY	KEY NO.	PART NUMBER	DESCRIPTION	QTY
1	511731001	Starter Grip.....	1	20	901552001	Outer Heat Dam Gasket.....	1
2	900849002	Starter Rope (42 in.)	1	21	518685001	Air Baffle.....	1
3	660466001	Screw (M4 x 18 mm)	11	22	518497001	Heat Dam	1
4	660970001	Screw (M4 x 16 mm)	4	23	901551001	Inner Heat Dam Gasket.....	1
5	308671009	Starter Housing Assembly	1	24	518504002	Rear Housing	1
6	300960002	Clutch Assembly	1	25	308892004	Short Block Assembly.....	1
7	638090001	Washer	1	26	660925003	Screw (M4 x 12 mm)	6
8	518692001	Starter Baffle	1	27	638337001	Crankcase Cover.....	1
9	638033001	Spring and Container	1	28	901550001	Crankcase Cover Gasket	1
10	310022003	Easy Starter Assembly	1	29	901452001	Muffler Gasket.....	1
11	638389001	Pulley Retainer	3	30	308990011	Muffler Assembly.....	1
12	638284002	Spacer Tube	1	31	638442001	Muffler Housing.....	1
13	650017001	Washer	1	32	660638003	Muffler Bolt (10-24 x 2-1/8 in.)	2
14	308811001	Flywheel Assembly.....	1	33	308863024	Electrical Lead Wire Assembly.....	1
15	308675001	Fuel Tank and Cap Assembly.....	1	34	850108002	Ignition Module	1
16	660970002	Screw (M4)	3	35	660968001	Screw (M4 x 19 mm)	2
17	660454007	Bolt (M5 x 70 mm).....	2	36	518777004	Air Box Cover	1
18	518766001	Air Box Base	1	37	561635001	Primer Bulb (Ruixing)	1
19	308054028	Carburetor Assembly (Ruixing)	1	38	518824001	Choke Lever (Ruixing)	1
	308054034	Carburetor Assembly (Zama)	1				

FIGURE C



PARTS LIST (FIGURE C)

KEY NO.	PART NUMBER	DESCRIPTION	QTY	KEY NO.	PART NUMBER	DESCRIPTION	QTY
1	940726013	Expand-it Label	1	14	638017001	Cupped Washer	1
2	940627027	Brushcutter Safety Label.....	1	15	678018001	Blade Nut	1
3	308035011	Straight Shaft Assy.....	1	16	660886001	Screw (1/4-20 x 1-1/4 in.).....	1
4	660736001	Screw (10-24 x 5/8 in.).....	1	17	308473001	Grass Deflector Assy (Incl. Key No. 16)	1
5	638125001	Clamp	1	18	678019001	Arbor.....	1
6	660642001	Screw (1/4-20 x 1-1/4 in.).....	1	19	310643001	String Head Housing	1
7	308210001	Gear Head	1	20	678022001	Spring	1
8	518367001	Spacer	1	21	310412001	Spool	1
9	678020001	Gear Head Locking Tool.....	1	22	308042003	Spool Retainer.....	1
10	638120001	Brushcutter Guard.....	1	23	309562002	String Head Assembly (Incl. Key Nos. 19-21)	1
11	660737001	Screw (10-24 x 1/2 in.)	3	24	310734002	Dual Spool™ Fixed Line String Head Insert	1
12	678011001	Flanged Washer	1				
13	638006004	Blade	1				