

RYOBI BLOWER – MODEL NUMBER RY40401




FIGURE A

PARTS LIST (FIGURE A)

KEY NO.	PART NUMBER	DESCRIPTION	QTY
1	941770003	Logo Label	1
2	941588029	Data Label	1
3	941657096	Icon Warnings Label.....	1
4	941781001	Tube Logo Label.....	1
5	525558001	Blower Tube	1
6	525803001	High Speed Nozzle.....	1

RYOBI BLOWER - MODEL NUMBER RY40401




FIGURE B

RYOBI BLOWER – MODEL NUMBER RY40401

The model number will be found on a label attached to the motor housing. Always mention the model number in all correspondence regarding your **BLOWER** or when ordering repair parts.

PARTS LIST (FIGURE B)

KEY NO.	PART NUMBER	DESCRIPTION	QTY
1	311178001	Handle Assembly	1
2	525552001	Switch Trigger	1
3	790009004	Wire Connector	2
4	679973002	Compression Spring	1
5	270503001	Switch Assembly	1
6	661817001	Screw (M4 x 14 mm)	25
7	230766001	Motor Assembly	1
8	570815001	Rubber Pad	2
9	525557001	Motor Mount	1
10	661861002	Screw w/Washer (M4 x 10 mm)	2
11	311179001	Blower Housing Assembly	1
12	308164004	Impeller Assembly	1
	Not Shown:		
	990000074	Operator's Manual	
	4-9-13		
	(Rev:01)		