

RYOBI
40 Volt Power Source
Model Number RYi300BG
Mfg. Numbers 099930356 and 099930631
Repair Sheet

ONE WORLD TECHNOLOGIES, INC.


P.O. Box 1288, Anderson, SC 29622 • Phone 1-800-525-2579

www.ryobitools.com

995000828

8-1-19 (Rev:01)

RYOBI 40 VOLT POWER SOURCE - MODEL NUMBER RYi300BG



RYOBI 40 VOLT POWER SOURCE – MODEL NUMBER RYi300BG

The model number will be found on a label attached to the motor housing. Always mention the model number in all correspondence regarding your **RECIPROCATING SAW** or when ordering repair parts.

PARTS LIST

KEY PART NO.	PART NUMBER	DESCRIPTION	QTY
1	518728023	Upper Housing	1
2	518728024	Back Housing Assembly (Inc. Key No. 12).....	1
3	518728025	Back Housing	1
4	315478001	Control Panel Assembly	1
5	518728028	Handle	1
6	518728027	Side Panel Vent	1
7	529685006	LED Task Light.....	1
8	660203001	Screw (M3 x 8 mm).....	1
9	662651001	Screw (M3 x 8 mm).....	2
10	660031017	Screw (M3.5 x 16 mm Torx Pan Hd.).....	12
11	T662318001	Screw (M4 x 13.5 mm).....	2
12	940705432	Logo Label.....	1
Not Shown:			
	995000827	Operator's Manual	