

Rider 1000/1200



1.1995

Spare parts

Ersatzteile

Pièces détachées

Reserve onderdelen

Repuestos

Reservdelar

Replaces

Ersetzt


Remplace

Vervangt


Reemplaza



Ersätter

106 23 44-63


A**B**



- * compl 506 88 67-01
- ** compl 506 88 70-01




C**D**

E



F**H**

G




J


* compl 506 75 11-01
* compl 506 75 11-03

Yttre. Outer. Exterieur. Äusser. Ulko.
Mitten. Centre. Centre. Zentrum. Keski.


R 1200



L







N



P

* compl 964 99 96-01




R


* compl 506 75 11-01 Yttre. Outer. Exterieur. Äusser. Ulko.

* compl 506 75 11-04 Mitten. Centre. Centre. Zentrum. Keski.


R 1000



S R 1000



T CAT



* compl 506 93 24-01

