

Rider 1000/1200



1.1995

Spare parts

Ersatzteile

Pièces détachées

Reserve onderdelen

Repuestos

Reservdelar

Replaces

Ersetzt


Remplace

Vervangt


Reemplaza



Ersätter

106 23 44-63


A**B**

- * compl 506 88 67-01
- ** compl 506 88 70-01




C**D**


E




F



H



G




J


* compl 506 75 11-01
* compl 506 75 11-03

Ytre. Outer. Exterieur. Äusser. Ulko.
Mitten. Centre. Centre. Zentrum. Keski.


R 1200




L




K R 1200




M



N




P




R

* compl 506 75 11-01 Yttre. Outer. Exterieur. Äusser. Ulko.
 * compl 506 75 11-04 Mitten. Centre. Centre. Zentrum. Keski.

R 1000



T CAT



* compl 506 93 24-01

