


H Husqvarna



7

Rider 1000, 1030-BIOCLIP, 1200



1.1996

Spare parts

Ersatzteile


Pièces détachées

Reserve onderdelen

Repuestos



Reservdelar

A




B


*compl 506 88 67-01
**compl 506 88 70-01




C




D




E




G



F




H




J

*compl 506 75 11-01 Yttre. Outer. Exterior. Äusser. Ulko.
*compl 506 75 11-03 Mitten. Centre. Centre. Zentrum. Keski.


R 1200






K R 1200



N







R

*compl 506 75 11-01 Yttre. Outer. Exterieur. Äusser. Ulko.
*compl 506 75 11-04 Mitten. Centre. Centre. Zentrum. Keski.


R 1000




S R 1000



T CAT




*compl 506 93 24-01



U

*compl 506 75 11-05 (a)
*compl 506 75 11-04 (b)

BIOCLIP



(a) = Yttre. Outer. Exterieur. Äusser. Ulko.
(b) = Mitten. Center. Centre. Zentrum. Keski.