


**H** Husqvarna

1994 -05- 1.1



# Rider

## 850-10/12/12,5K



**1.1994**

**Spare parts**

**Ersatzteile**

**Pièces détachées**

**Reserve onderdelen**

**Repuestos**

**Reservdelar**

**Replaces**

**Ersetzt**

**Remplace**


**Vervangt**

**Reemplaza**


**Ersätter**

**106 23 46-63**



**A**



**B**







**E****F**

# G


(10) = 10 hp B & S  
 (12) = 12 hp B & S  
 (12,5 K) = 12,5 hp Kawasaki




# H





I




J




**K****L**

# M



# N




\* compl.506 53 34-01Yttre. Outer. Exterior. Äusser. Ulko.




\* compl.506 53 34-01Mitten. Centre. Centre. Zentrum. Keski.



O



P



Q

Leverans endast som reservdel  
 Delivery as spare part only  
 Nur als Ersatzteil lieferbar  
 Livrable seulement comme pièce de rechange  
 Solo como repuesto  
 Zasilá se jenom jako náhradní díl

