


# Rider 850-8/12





**1. 1990**  
**Spare parts**  
**Ersatzteile**  
**Pièces détachées**  
**Reserve onderdelen**  
**Repuestos**  
**Reservdelar**

**A**

725 24 69-51 D  
506 76 15-01 D



506 76 11-01 D  
506 76 72-01 D  
732 21 18-01 D



506 55 62-01

506 54 80-01

506 56 56-01

506 56 53-01  
506 55 63-01

734 11 64-01  
506 56 55-01

734 11 53-01  
506 55 80-01

**F**

\* compl 506 50 09-01

506 51 64-01

728 83 62-05  
506 55 43-01

506 56 26-01  
506 55 46-01

506 53 94-01  
735 31 14-21

\* 732 21 20-51  
\* 506 67 57-01  
\* 735 31 40-10  
\* 738 22 04-19  
\* 506 50 08-01

505 55 43-01  
506 55 44-01  
735 31 18-01

732 21 20-51


721 23 20-51

506 58 91-01

506 50 07-01 \*  
725 24 97-51 \*


506 55 47-01

735 31 14-21  
506 52 24-01




**B**


\* compl 506 56 62-01 (8hp)




C




D






**G**




H






J

compl 506 56 04-01  
compl 506 56 04-02



# K





\* compl 506 53 34-01  
\* compl 506 53 34-02

Yttre. Outer. Exterieur. Äusser. Ulko.  
Mitten. Centre. Centre. Zentrum. Keski.


\* 506 51 85-01  
506 53 35-01

L

\* compl 506 55 48-01



**M**



**N**


506 66 11-01  
506 57 11-01

**Husqvarna**


506 66 27-01




506 66 10-02  
506 66 10-04




506 66 10-03  
506 66 10-01









P



**R**



S



\* compl 964 99 55-01