







Parts Breakdown

SJ401

Products with multiple versions are listed in subsiding order with the newest version on top not indented

| <u>Fig #</u> | <u>Part ID</u> | <u>Part Name</u> | <u>Quantity</u> |
|--------------|----------------|--------------------------------|-----------------|
| 1 | 240051-000 | BASE, SJ401 | 1 |
| 2 | 020720-003 | SCREW & WASHER M8, SJ401 | 4 |
| 3 | 900567-000 | BODY, SJ401 | 1 |
| 4 | 303209-000 | HOSE, SJ401 | 1 |
| 5 | 270308-000 | PLATE COVER, SJ401 | 1 |
| 6 | 303202-000 | BLADE STORAGE CASE, SJ401 | 1 |
| 7 | 024201-001 | PULL NAIL, SJ401 | 2 |
| 8 | 020106-013 | SCREW, SJ401 | 2 |
| 10 | 990026-000 | MOTOR, SJ401 | 1 |
| 11 | 020723-005 | SCREW & WASHER, SJ401 | 3 |
| 12 | 080171-000 | POWER CORD, SJ401 | 1 |
| 13 | 060047-000 | SPACER, SJ401 | 1 |
| 14 | 240042-000 | COUNTERWEIGHT, SJ401 | 1 |
| 15 | 020508-001 | SET SCREW, SJ401 | 1 |
| 16 | 020613-001 | HEX SOCKET BOLT, SJ401 | 1 |
| 17 | 021200-001 | SPRING WASHER, SJ401 | 1 |
| 18 | 021101-027 | FLAT WASHER, SJ401 | 1 |
| 19 | 225070-000 | HOLD DOWN BLOCK, SJ401 | 1 |
| 20 | 290079-000 | SUPPORT ROD, SJ401 | 1 |
| 21 | 020505-003 | SET SCREW, SJ401 | 1 |
| 22 | 270309-000 | HOLD DOWN FOOT, SJ401 | 1 |
| 23 | 020601-003 | HEX SOCKET BOLT, SJ401 | 1 |
| 24 | 270310-000 | BLADE SUPPORTER & GUARD, SJ401 | 1 |
| 25 | 021104-023 | FLAT WASHER, SJ401 | 1 |
| 26 | 290081-000 | DUST BLOWER, SJ401 | 1 |
| 27 | 026104-001 | PIN SPRING, SJ401 | 1 |
| 28 | 303071-001 | KNOB, SJ401 | 1 |
| 29 | 270248-000 | BUSING SET COVER, SJ401 | 1 |
| 30 | 020103-015 | SCREW, SJ401 | 2 |
| 31 | 913002-000 | BUSHING, SJ401 | 2 |
| 32 | 303203-000 | BOARD COVER, SJ401 | 1 |
| 33 | 020103-015 | SCREW, SJ401 | 2 |
| 34 | 020103-015 | SCREW, SJ401 | 4 |
| 35 | 090033-001 | SWITCH, WASHER, NUT, SJ401 | 1 |
| 36 | 303207-000 | CONTROL KNOB, SJ401 | 1 |
| 37 | 303259-000 | SWITCH COVER (PLASTIC), SJ401 | 1 |
| 38 | 863301-003 | INDICATION LABEL, SJ401 | 1 |
| 39 | 290080-000 | LOCK POST, SJ401 | 1 |
| 40 | 022301-001 | NUT, SJ401 | 1 |
| 41 | 020228-001 | SCREW, SJ401 | 2 |
| 42 | 302043-000 | SWITCH CASE, SJ401 | 1 |
| 43 | 020200-001 | SCREW, SJ401 | 4 |
| 44 | 021308-001 | EXT. TOOTH WASHER, SJ401 | 1 |
| 45 | 021306-001 | LOCK WASHER, SJ401 | 2 |
| 46 | 224053-000 | TABLE, SJ401 | 1 |
| 47 | 270311-000 | TILT BRACKETT, SJ401 | 1 |
| 48 | 020219-001 | SCREW, SJ401 | 3 |
| 49 | 021101-025 | FLAT WAHER, SJ401 | 1 |
| 50 | 270249-000 | POINTER, SJ401 | 1 |
| 51 | 020601-003 | HEX SOCKET BOLT, SJ401 | 1 |
| 52 | 021104-023 | FLAT WASHER, SJ401 | 1 |
| 53 | 020601-003 | HEX SOCKET BOLT, SJ401 | 1 |
| 54 | 021104-023 | FLAT WASHER, SJ401 | 1 |
| 56 | 040026-001 | BLADE CHANGE ROD, SJ401 | 1 |
| 58 | 020726-001 | PAN HEAD SCREW, SJ401 | 1 |
| 59 | 020614-001 | SOCKET HEAD SCREW, SJ401 | 1 |
| 60 | 021402-001 | WAVE WASHER, SJ401 | 1 |
| 61 | 080177-000 | GROUND WIRE, SJ401 | 1 |
| 62 | 225111-000 | ARM COVER(RIGHT), SJ401 | 1 |
| 63 | 225112-000 | ARM COVER <LEFT), SJ401 | 1 |
| 64 | 053014-000 | BEARING FLANGE, SJ401 | 1 |
| 65 | 330026-000 | AIR DIAPHRAGM, SJ401 | 1 |
| 66 | 020702-001 | COVER SET SCREW, SJ401 | 1 |
| 67 | 224041-000 | UPPER ARM, SJ401 | 1 |



Parts Breakdown

SJ401

| | | | |
|-----|------------|-------------------------------|---|
| 68 | 290077-000 | ARM PIN, SJ401 | 1 |
| 69 | 224042-000 | LOWER ARM, SJ401 | 1 |
| 70 | 270251-000 | CONNECTOR, SJ401 | 1 |
| 71 | 028935-001 | SET SCREW, SJ401 | 1 |
| 72 | 021202-003 | SPRING WASHER, SJ401 | 1 |
| 73 | 022101-001 | NUT, SJ401 | 1 |
| 74 | 026102-007 | PIN, SJ401 | 1 |
| 75 | 026103-015 | ROLL PIN, SJ401 | 1 |
| 76 | 225069-000 | BLADE TENSION LEVER, SJ401 | 1 |
| 77 | 290078-000 | TENSION ADJUSTING BOLT, SJ401 | 1 |
| 78 | 021100-011 | FLAT WASHER, SJ401 | 1 |
| 79 | 026104-009 | PIN, SJ401 | 1 |
| 80 | 020600-001 | HEX SOCKET BOLT, SJ401 | 1 |
| 81 | 060052-000 | SPACER, SJ401 | 1 |
| 82 | 303201-000 | ARM LINK, SJ401 | 1 |
| 83 | 050012-000 | BEARING, SJ401 | 1 |
| 84 | 270252-000 | BEARING FENCE, SJ401 | 1 |
| 85 | 020200-005 | SCREW M4X8, SJ401 | 1 |
| 86 | 021101-027 | FLAT WASHER, SJ401 | 1 |
| 87 | 022101-001 | NUT, SJ401 | 1 |
| 88 | 026202-007 | PIN, SJ401 | 1 |
| 89 | 225073-000 | BLADE SUPPORT, SJ401 | 1 |
| 90 | 029141-001 | SPRING, SJ401 | 1 |
| 91 | 250005-000 | UPPER BLADE HOLDER, SJ401 | 1 |
| 92 | 250006-000 | UPPER BLADE PAD, SJ401 | 1 |
| 93 | 020608-003 | HEX SOCKET BOLT, SJ401 | 1 |
| 94 | 026103-015 | ROLL PIN, SJ401 | 1 |
| 95 | 250003-000 | LOWER BLADE HOLDER, SJ401 | 1 |
| 96 | 250004-000 | LOWER BLADE NUT, SJ401 | 1 |
| 98 | 026107-001 | PIN, SJ401 | 1 |
| 99 | 029144-001 | COMPRESSION SPRING, SJ401 | 1 |
| 100 | 330029-000 | ARM COVER RUBBER CUP, SJ401 | 4 |
| 101 | 900313-003 | CONTROL BOARD ASSY, SJ401 | 1 |
| 102 | 900403-000 | LOCK HANDLE, SJ401 | 1 |
| 103 | 053014-000 | BEARING FLANGE, SJ401 | 1 |
| 104 | 022101-001 | NUT, SJ401 | 1 |
| 105 | 021202-003 | SPRING WASHER, SJ401 | 1 |
| 106 | 053014-000 | BEARING FLANGE, SJ401 | 1 |
| 107 | 028935-001 | SET SCREW, SJ401 | 1 |
| 108 | 053014-000 | BEARING FLANGE, SJ401 | 1 |
| 109 | 290077-000 | ARM PIN, SJ401 | 1 |
| 110 | 050012-000 | BEARING, SJ401 | 1 |
| 111 | 026103-015 | ROLL PIN, SJ401 | 1 |
| 112 | 020608-003 | HEX SOCKET BOLT, SJ401 | 1 |
| 113 | 026107-001 | PIN, SJ401 | 1 |