



Parts List for SPCM1936 Type 1

Item Number	Part Number	Description	Qty Required
2	90150275	CONNECTING PLATE ASS	1
3	90560546	ROD	1
4	90151278	FLAP	1
5	241658-03	RING,PUSH	4
6	90560547	ROD	1
7	90556984	DOOR,REAR	1
8	242380-00	SPRING,TORSION	1
9	90560821	PLATE ASSY.	1
10	90560820	PLATE ASSY.	1
11	098128-25	BOLT, CARRIAGE	4
12	90560803	FLANGE NUT	7
13	90555016	HANDLE REST	1
14	242364-05	FRONT AXLE	1
15	90587727	STRAP	1
16	90555668	ROD	1
17	90153286	DOOR	1
18	90139684	PLATE	1
19	241594-02	SPACER	3
20	90589084	MOTOR ASSEMBLY	1
21	243679-00	SCREW	3
22	680812-00	SPACER,BLADE	1
23	90547431	FAN	1
24	90541433-01	MULCH BLADE	1
25	90541434	BLADE INSULATOR	1
26	092715-00	SPACER	1
27	90561895	HEX NUT	1
28	90560495	BRUSH W/LEAD	1

Parts List for SPCM1936 Type 1

Item Number	Part Number	Description	Qty Required
29	90563946	TRANSMISSION ASSY.	1
30	330019-73	SCREW	4
31	90558819	SPACER	4
32	90136118	CONNECTING ROD	1
33	90555912	MOTOR & GEARBOX	1
34	241656-00	SPRING	1
35	90138316	HANDLE GRIP	1
36	90138315	ADJUST LEVER	1
37	90560321	SPRING	1
38	90562058	KNOB ASSEMBLY	1
39	90551430	STUD	2
40	90560898	UPPER HANDLE	1
41	90104297	SHOULDER BOLT	2
42	90564441	RETAINING CLIP	1
43	90564442	RETAINING CLIP	1
44	099361-10	WASHER	2
45	241693-00	KEPS NUT	2
46	90153493-01	SHROUD ASSY.	1
47	605111-00	WASHER	2
48	90556000	HEIGHT INDICATOR	1
49	330045-13	SCREW,TAPTITE	3
50	90546217	CONNECTOR ASSY	1
51	242488-00	WASHER	4
52	90556107	7INCH WHEEL	2
53	624374-00	RING,PUSH	2
54	90555873	WHEEL COVER	2
55	90134361	WHEEL ASSEMBLY	2

Parts List for SPCM1936 Type 1

Item Number	Part Number	Description	Qty Required
56	90560897	BOLT	2
57	90556609	HUB CAP	4
58	90153492	SHROUD FRONT	1
59	90546535	LOCK LEVER	1
60	90546536	CLAMP	1
61	239715-06	WRAP,TIE	5
62	90589023	BATTERY PK.ASSY	1
63	90530033	KEY	1
64	90547825	FRAME,BAG	1
65	242501-05	GRASS BAG	1
66	330019-13	SCREW,M4X19	28
68	488772-00	HEX HEAD SCREW	2
69	90560410	NAMEPLATE	1
70	90560411	HEIGHT ADJ LABEL	1
71	90560412	LABEL	1
72	90560413	LABEL,IDENT.	1
73	90560414	LABEL	1
74	90560415	LABEL	1
75	90560417	LABEL	1
76	90564186	LABEL	1
77	90564910	LABEL	1
78	90541668	LABEL,INFO.	1
79	90541669	DANGER LABEL	1
80	90541818	LABEL,SWTCH.HSG	1
81	90508749	DANGER LABEL	1
82	90512672	DANGER LABEL	1
83	90508752	DANGER LABEL	1

Parts List for SPCM1936 Type 1

Item Number	Part Number	Description	Qty Required
84	90561303	INFORMATION LABEL	1
85	90560416	INFORMATION LABEL	1
86	90560422	INFORMATION LABEL	1
90	90540793	BAIL BAR	1
91	90149408	BAIL BAR	1
95	330019-13	SCREW,M4X19	2
96	240808-01	CAP,BRUSH	2
97	242207-00	SPRING,BRUSH	2
98	070162-00	TERMINAL	2
99	242274-00	INSERT,BRUSH	2
100	90541817	MACHINE SCREW	4
101	903693	NUT	4
102	90534860	SWITCH (ON-OFF)	1
102	90149389	SWITCH ASSEMBLY	1
103	90560489	CORD HOLDER	2
106	90587674	KNOB	2
107	90564730	SPRING PIN	2
108	90101536	COMPRESSION SPRING	2
109	90587673	PIN	2
110	330019-13	SCREW,M4X19	5
111	90541477	SPRING	1
112	638313-00	SWITCH	1
113	384127-01	SCREW	3
114	330019-40	SCREW	2
115	90560294	CORDSET	1
116	90556171	CLAMSHELL SET	1
117	90541597	CRANK	1

Parts List for SPCM1936 Type 1

Item Number	Part Number	Description	Qty Required
118	90541599	CRANK	1
119	90541598	BUTTON	1
120	000000-00	No Longer Available	1
121	90564126	BRUSH W/LEAD	1
122	90558818	COUPLING	1
123	90541476	TORSION SPRING	1
871	90547460	CHARGER	1