


PARTS LIST - RYOBI SS720r
Serial no. 406147515 and greater.



<u>ITEM</u>	<u>PART NO.</u>	<u>PART NAME</u>
1	612605	Hanger
2	180689	Driver Shaft Housing
3	683608	Flexible Drive Shaft
4	153597	Clamp Assembly
5	180547	Guard Mounting Hardware
6	145569	Anti-Rotation Screw
7	180549	Gearbox Assembly
8	180548	Guard and Blade Assembly
9	180553	Blade Assembly
10	153619	Outer Spool and Eyelet Assembly

<u>ITEM</u>	<u>PART NO.</u>	<u>PART NAME</u>
11	145566	Eyelet
12	610660	Retainer (10 pack)
13	610317	Spring
14	153600	Inner Reel
15	153066	Bump Knob
*	610375	Monofilament Line, 50 feet
*	153577	Spool and Line Assembly
*		not shown