



BOSCH

Circular hand saw

TKS 7000 | 3 601 F76 080

Table of Content

Spare parts list.....	2
Illustration - Type.....	4

Spare parts list

Item	Part Number	Description
2	1 619 P08 314	Field 230V
4	1 619 P09 972	Switch
5	1 604 460 225	Power supply cord H07 RN-F CN 2,65m 2 x 1,5mm
6	2 600 703 017	Grommet Ø6,4-Ø7,2x76 MM
7	1 619 P06 313	Cable Clip
11	1 619 P06 286	Insulating Cap
12	1 619 P06 210	Suppression Filter
13	1 619 P00 456	Ball Bearing 7x19x6 MM
14	1 900 905 173	groove ball bearing 6000-2RS DIN 625
19	2 603 490 021	Torx Oval-Head Screw 4x12
24	1 619 P09 797	Baffle
26	1 619 P09 801	Set Of Handles
27	1 619 P06 227	Rubber Ring
28	1 619 P10 065	Connecting Cable
38	1 619 P09 795	Guide Bracket
39	2 610 936 576	Compression Spring
50	1 619 P06 230	Washer
51	1 619 P10 086	Locking Washer
52	1 619 P06 232	Screw
54	1 619 P06 238	Locking Washer
57	F 000 640 007	O-Ring
58	1 619 P09 803	Pivoting Blade Guard
60	1 619 P09 794	Extension Spring
61	1 619 P06 236	Bumper BLACK
67	1 619 P10 608	Slotted Spring Pin
76	1 619 P06 244	Wing Nut
77	2 916 021 013	Plain Washer 8-ST
78	1 619 P06 211	Round-Head Bolt
80	1 619 P10 037	Lever
81	1 619 P09 798	Nut
83	1 619 X01 792	Spring BLACK
84	1 619 P17 212	Cover
85	1 619 P01 618	Wing Screw BLACK
87	2 603 490 022	Screw 4x16

Spare parts list

Item	Part Number	Description
88	2 610 925 864	Screw
92	1 619 P09 874	Support plate
93	1 619 P06 246	Screw
94	2 610 924 687	Countersunk-Head Screw
653	1 619 X05 789	Parallel-Guide
801	1 619 P10 061	Motor Housing BLUE
803	1 619 P10 062	Armature set 230V
808	1 619 P09 998	Nameplate
810	1 619 P10 063	Carbon-Brush Set
830	1 619 P14 506	Offset Screwdriver
850	1 619 P10 066	Gear
866	1 619 P10 067	Protective Cover
869	1 619 P10 195	Base Plate

Illustration - Type - E

