



## Parts List for TR100 Type 1

Item Number	Part Number	Description	Qty Required
1	000000-00	No Longer Available	1
3	000000-00	No Longer Available	1
4	000000-00	No Longer Available	1
5	000000-00	No Longer Available	1
6	387378-00	SPRING	2
7	152872-00	HOLDER,BRUSH	2
8	387542-00	BRUSH	2
9	330019-09	SCREW	2
10	389626-00	RUBBER PLUG	1
11	157315-00	WASHER,SPRING	1
14	148991-01	CASE,GEAR	1
15	000000-00	No Longer Available	1
16	383994-00	SWITCH,ON/OFF	1
18	680131-01	RECEPTACLE	1
19	87486-00	CONTACT,TERM.	1
23	90516433SV	GEAR ASSY	1
24	000000-00	No Longer Available	1
25	603759-01	BLADE ASSEMBLY	1
26	071653-13	SPACER	2
27	071653-13	SPACER	1
28	381980-00	NUT,STOP	5
29	88782-00	SCREW	5
30	397589-00	WASHER	1
31	158495-00	SCREW,TAPTITE	4
32	330019-04	SCREW,PLASTITE	7
33	000000-00	No Longer Available	1
34	133952-00	WASHER	1

## Parts List for TR100 Type 1

Item Number	Part Number	Description	Qty Required
35	330045-05	LOCK SCREW	3
36	382791-00	SPRING,FLAT	1
37	330001-08	BEARING,SLEEVE	1
39	151625-00	BLADE,POLARIZED	1
40	000000-00	No Longer Available	1
42	150844-01	PAD	2
43	382745-00	LEVER,LOCKOFF	1
44	000000-00	No Longer Available	1
45	000000-00	No Longer Available	1
846	679853-00	BLADE SPACER KT	1