




800



TR315 (Extended Magazine)

Parts List for TR315 Type 0

Item Number	Part Number	Description	Qty Required
1	SC18	SCREW- BUTTON HEAD C	1
2	SC15	NUT- JAM	1
3	SC28	WASHER- SHAKEPROOF	1
4	B01426	DEFLECTOR- AIR	1
5	B03043	REAR VALVE SEAT	1
6	SC09	O-RING H70-013	1
7	B01419	SPRING- THROTTLE CON	1
8	B01420	LOCATOR- THROTTLE VA	1
9	SC21	SCREW- SOCKET HEAD C	2
10	B01455	WASHER- THROTTLE VAL	2
11	B01421	SUPPORT- O-RING END	4
12	SC08	O RING	5
13	B01422	SUPPORT- O-RING CENT	2
14	B03044	SPACER- THROTTLE VAL	1
15	TR313015AF	ASSY- HOUSING	1
16	B03042	FRONT VALVE SEAT	1
17	B01425F	STEM- THROTTLE	1
18	AB01473F	ASSY- INLET BUSHING	1
19	B01435F	TRIGGER GUARD	1
20	SC18	SCREW- BUTTON HEAD C	1
21	B01413	LINER	1
22	SC23	SCREW- SET	1
23	SC10	O RING	1
24	SC13	NUT- NYLOCK	1
25	B01414F	PISTON	1
26	B01443	CYLINDER GASKET	1
27	TR309027	ASSY- PISTON STOP	1

Parts List for TR315 Type 0

Item Number	Part Number	Description	Qty Required
28	B01858	BUSHING- PISTON ROD	1
29	TR105015	CLEVIS LOCK SCREW	1
30	SC36	PIN- ROLL	1
31	TR105020	JAW PINS	1
32	TR309032F	CLEVIS	1
33	TR309033F	LINK- ARM LEFT	1
34	TR309034F	LINK- ARM RIGHT	1
35	TR309035	BUSHING	1
36	TR309036F	SLIDE- MACH.	1
37	SC32	WASHER- LOCK	5
38	TR309038F	SPACER	2
39	000000-00	No Longer Available	4
40	TR309040F	JAW-LEFT M/F TLTR309	1
41	TR309041F	JAW-RIGHT M/F TLTR30	1
42	TR417042F	ASSY- CARRIAGE	1
43	TR105026	TEETH- ROLL PIN FOR	2
44	TR105025CF	TEETH- FLARED (CURVE	1
44	TR105025F	TEETH- REPLACEABLE	1
45	TR309045	PISTON ROD	1
46	SC40	PIN- GROOVE	1
47	TR309047F	BRACKET- TRIGGER GUA	1
48	SC05	PIN- ROLL	3
49	A02073F	TRIGGER- LTWT FINISH	1
50	TR419051F	ASSY- MAGAZINE	1
51	TR107027F	ASSY- PUSHER LONG GA	1
53	B01417	BUSHING- THROTTLE	1
54	TR313056	SPRING- COMPRESSION	1

Parts List for TR315 Type 0

Item Number	Part Number	Description	Qty Required
55	TL726000	#6 SPLIT LOCKWASHER	1
56	TL716208	SOC HD CAP SCREW W/P	1
90	159919	LABEL-WARNING-MIIICN	1
800	100679	LUBE (1LB.CAN)	1
800	100653	LUBE (2CC)	1